



 1988-1989

Electrical Troubleshooting Manual

Canada & USA

Downloaded from Canadian Prelude Club

PRELUDE
INFAMOUZ

Contents

How To Use This Manual	2
Troubleshooting	2-12
Fuse Information	6
Circuit Schematics (see Circuit Index)	
Component Location Photographs	201
Harness Routing	203

Circuit Index

Air Conditioner:	
Air delivery	64
Blower control	62
Compressor control	63
Fans	63
Automatic seat belt	146
Automatic transmission: PGM-CARB	39
Automatic transmission: PGM-FI	39-8
Back up lights	112
Brakelights	110-12
Brake warning system	71
Charging system	22
Cigarette lighter	114-2
Clock	154
Console lights	117
Coolant temperature gauge	81
Cruise control	34 *
Dash fuse box	11
Dash lights	117
Dome light	114
Entry light timer system	115
Fog lights	100-2
Front side marker lights	110
Fuel gauge	81
Gauges	81
Ground distribution	14
Hazard lights	110-6
Headlights	100
Headlight switch	12
Horns	40
Ignition system: PGM-CARB	20
Ignition system: PGM-FI	20-2
Indicators	80
Integrated control unit	70
Key-on warning	73
License plate lights	110-10
Lights-on warning	73
Low fuel warning system	74
Oil pressure warning system	72
Parking lights	110-4
PGM-CARB	23
PGM-FI	24
Power antenna	151
Power distribution	10
Power door locks	130
Power door mirrors	141
Power windows	120
Rear side marker lights	110-10
Rear window defogger	61
Retractable headlights	102
Safety indicator	84
Shift lever position indicator	89
Speed sensor	33
Starting system	21
Stereo sound system	150
Sunroof	122
Tachometer	81
Taillights	110-10
Trunk light	114
Turn signal lights	110-6
Wiper/washer	91

First Edition 10/88
All Rights Reserved

American Honda Motor Co., Inc.
Service Publications

How To Use This Manual

Page Numbering System

This manual divides the electrical system into individual sections. Each section has a unique section number. For example, the wiper/washer circuit is section 90, the wiper/washer-pulse circuit is section 91, and the rear wiper/washer circuit is 92. Component Location photographs and Harness Routing drawings are at the back of the manual in sections 201 and 203 respectively.

Within a section, the first section page uses the section number and then the remaining pages are numbered using the section number, a dash, and then a consecutive number. So, if there are three pages in section 90, the pages will be numbered 90, 90-1, and 90-2.

In addition, the sections are not numbered sequentially, and in many cases, numbers have been left out to leave room for possible additions to reflect the new features for next year or new model types.

Outline of Each Circuit Section

Each circuit section will have a **Circuit Schematic** (wiring diagram), a **Component Location Index**, and a **System Description**. Certain complex circuits will also have **System Operation** charts, **Quick-Checks**, and **Troubleshooting** procedures.

1. A **Circuit Schematic** starts off each section. Schematics show:
 - how all the components within a circuit work together.
 - current flow from the power source (at top of page) to ground (at bottom of page).
 - switch positions (shown "at rest" as if the ignition was off).
 - special instructions ("Solid-State: Do not check resistance").
 - those circuits sharing a common power source or ground.
2. A **Component Location Index** follows each schematic and lists:
 - major components, connectors, and grounds for that particular schematic.
 - the physical locations of each component, connector, and ground.
 - the number of cavities within and the color of each connector.
 - the page number showing photos of each component, connector, and ground.
3. A **System Description** follows the index, and gives a concise explanation of the basic operation of that particular circuit.
4. A **System Operation** chart follows (if required), which describes how the circuit should normally operate, to help you quickly validate the symptom.
5. Next, a list of **Quick-Checks** follows (if required) explaining how to quickly test for proper operation of fuses, grounds, and components without the help of any special equipment. For example: "Check fuse 13 by sounding the horn."
6. Last are the **Troubleshooting** procedures (if required), which are step-by-step instructions leading to diagnosis and repair.

New Features

New for this year is Section 202 - **Harness Connector Views**. The views are shown from the wire side of the female connectors, and only connectors with 6 or more pins are shown. Also, the number in each cavity corresponds to the number found next to the same connector on the schematic.

How To Use This Manual

Symbols

The abbreviations and symbols explained here are used throughout the manual; you'll need to know what they mean before you can use the schematics effectively.

Wire Color Abbreviations

The following abbreviations are used to identify wire colors in the circuit schematics:

BLK	black
BLU	blue
BRN	brown
GRN	green
GRY	gray
LT BLU	light blue
LT GRN	light green
ORN	orange
PNK	pink
RED	red
WHT	white
YEL	yellow

Wires

A wavy line means the wire is broken by the binding of the book but continues on the next page.




Wire insulation can be one color, or one color with another color stripe. (The second color is the stripe.)




This means the current path continues on another page. (The arrow shows direction of current flow.) To follow the white wire in this example, you would turn to the Power Distribution schematic and look for the "P" arrow.




This means the wire connects to another circuit. The wire is shown again in the circuit the arrow is pointing to.



A broken line means only some of the circuit is shown; refer to the circuit listed for the complete schematic.




Wire choices for options or different models are labeled, and shown with a "choice" bracket like this.





Where separate wires join, only the splice is shown; for details on the additional wiring, refer to the circuits listed.

OK here if Horn works; if not, see Power Distribution, page 10-1.




This dashed line means the BLU/RED and RED/BLU wires are both in connector C134.






Splices — “S”

Splices (S) are numbered and shown as a dot. The location and connection of these splices may change depending on manufacturer.




Connectors — “C”


Each connector (C) is numbered for reference in the component location index.




The index also lists the total number of cavities and the color of the connector. Wires may not be used in all cavities.




This means the connector connects directly to the component.



This indicates the connector connects to a lead (pigtail), wired directly to the component.



This indicates a screw terminal on the component.




Components


A solid line means the entire component is shown.



A broken line indicates only part of the component is shown.



The name of the component appears next to its upper right corner.




BRAKE SWITCH
Closed with pedal depressed.

Notes about component function follow its name.

Grounds — “G”

This symbol means the end of the wire is attached to a metal part of the car.



Each wire ground (G) is numbered for reference in the component location index.


This ground symbol (dot and 3 lines) overlapping the component means the housing of the component is attached directly to a metal part of the car.



How To Use This Manual


Symbols (cont'd)

This represents RFI (Radio Frequency Interference) shielding around a wire. The shielding is always connected to ground.




Fuses

This means power is supplied with the ignition in RUN.



Switches

These switches move together; a dashed line shows a mechanical connection between them.





Diode

The diode allows current to flow only in the direction of the arrow.



This is a relay shown with no current flowing through its coil.





How To Use This Manual

Circuit Schematics

Circuit schematics break the entire electrical system into individual circuits. Electrical components that work together are shown together. You are not distracted by wiring that is not part of the circuit you are working on.


Each drawing is arranged so current flows from positive, at the top of the page, to ground, at the bottom of the page. The "hot" labels at the top of a fuse show when the ignition switch supplies power to that fuse.


Each circuit is shown completely and independently on one schematic. Other circuits getting their power from the same point, or grounding at the same point are not shown. However, if other circuits actually share some wires with the circuit shown, the shared wires of the other circuits will also be shown.

Wires that connect to another circuit are shown with an arrowhead pointing in the direction of current flow. The name of the circuit or component that shares the wiring is provided for reference. You can check shared wiring by checking the operation of the other circuits.

"See Dash Fuse Box" means there are more connections to other circuits that are not shown. All such shared circuits are shown on the Dash Fuse Box circuit schematic. "See Ground Distribution" means there are more shared ground circuits which are shown on the Ground Distribution schematic.

The note "OK here if Glove Box Light works; if not, see Ground Distribution Page 14-1" is a troubleshooting aid. Check the glove box light by opening the glove box and observing the light. If it works, the ground circuit is OK from that point to the ground. In the dash fuse box circuit the circuit is good from that point to the fuse.






Power Distribution

The sample Power Distribution schematic shows how voltage is supplied from the positive battery terminal to the various circuits in the car.

Individual circuit schematics begin with a fuse. Power Distribution shows the wiring between the battery and the fuses. By combining Power Distribution with any individual schematic, you get a complete picture of how voltage is applied to the circuit.




How To Use This Manual


Circuit Schematics (cont'd)

Dash Fuse Box

The sample Dash Fuse Box schematic shows how voltage is supplied from the fuse to each individual component.


You can use the Dash Fuse Box circuit to speed your troubleshooting. If the Dash Fuse Box circuit shows that an inoperative circuit and a second circuit share a fuse, check the operation of the second circuit. If it works, you know the fuse is good and voltage is available to the inoperative circuit. You can then continue troubleshooting.






Headlight Switch

The sample Headlight Switch schematic shows how voltage is supplied from the headlight switch to each individual component.






How To Use This Manual


Circuit Schematics (cont'd)

Ground Distribution

This sample Ground Distribution schematic shows which components share the same two ground points.

All wires shown are black unless otherwise designated.





Component Location

A component location index follows each schematic. It lists every component, connector and ground in that circuit and describes its location in the car. The index also gives references to photographs of component locations which are located in Section 201.

Component Location Index

(Refer to Section 201 for photographs.)

C446 (23-GRN)	73
Under right side of dash	
C462 (10-WHT)	107
On center of floor, near gear selector	
C466 (12-WHT)	93
On automatic transmission control unit	
C467 (18-WHT)	93
On automatic transmission control unit	
C710 (7-WHT)	82
Behind gauge assembly	
C711 (10-WHT)	82
Behind gauge assembly	
C713 (16-WHT)	82
Behind gauge assembly	
C723 (4-WHT)	95
Under left side of dash, on dash fuse box	
G151	111
On right front of engine	
G401	75
Behind top center of dash	
G471	20
Right front of trunk area	

How To Use This Manual

Five-Step Troubleshooting

1. Verify The Complaint

Turn on all the components in the problem circuit to check the accuracy of the customer complaint. Note the symptoms. Do not begin disassembly or testing until you have narrowed down the problem area.

2. Analyze The Schematic

Look up the schematic for the problem circuit. Determine how the circuit is supposed to work by tracing the current paths from the power source through the circuit components to ground. Also, trace circuits that share wiring with the problem circuit. The names of circuits that share the same fuse, ground, or switch, and so on are referred to on each circuit schematic. Try to operate any shared circuits you didn't check in step 1. If the shared circuits work, the shared wiring is OK, and the cause must be in the wiring used only by the problem circuit. If several circuits fail at the same time, the fuse or ground is a likely cause.

Based on the symptoms and your understanding of the circuit's operation, identify one or more possible causes of the problem.

3. Isolate The Problem By Testing The Circuit

Make circuit tests to check the diagnosis you made in step 2. Keep in mind that a logical, simple procedure is the key to efficient troubleshooting. Test for the most likely cause of failure first. Try to make tests at points that are easily accessible.

4. Fix The Problem

Once the specific problem is identified, make the repair. Be sure to use proper tools and safe procedures.

5. Make Sure The Circuit Works

Turn on all components in the repaired circuit in all modes to make sure you've fixed the entire problem. If the problem was a blown fuse, be sure to test all of the circuits on that fuse. Make sure no new problems turn up and the original problem does not recur.

Test Equipment

Voltmeter and Test Light

CAUTION: A number of circuits include solid-state devices. Voltages in these circuits should be tested only with a 10-megohm or higher impedance digital multimeter. Never use a test light on circuits that contain solid-state devices. Damage to the device may result.

On circuits without solid-state devices, use a test light to check for voltage. A test light is made up of a 12-volt bulb with a pair of leads attached. After grounding one lead, touch the other lead to various points along the circuit where voltage should be present. The bulb will go on if there is voltage at the point being tested.


A voltmeter can be used in place of a test light. While a test light shows whether or not voltage is present, a voltmeter indicates how much voltage there is.

Self-Powered Test Light and Ohmmeter


CAUTION: Never use a self-powered test light on circuits that contain solid-state devices. Damage to these devices may result.

Diodes and solid-state devices in a circuit can make an ohmmeter give a false reading. To find out if a component is affecting a measurement, take one reading, reverse the leads, and take a second reading. If the readings differ, the component is affecting the measurement.

An ohmmeter can be used in place of a self-powered test light. The ohmmeter shows how much resistance there is between two points along a circuit. Low resistance means good continuity.



Self-Powered Test Light




Circuits that contain solid-state devices should only be tested with a 10-megohm or higher impedance digital multimeter.

Use a self-powered test light to check for continuity. This tool is made up of a light bulb, battery, and two leads. If the leads are touched together, the bulb will go on.

A self-powered test light is only used on an unpowered circuit. First disconnect the battery or remove the fuse that feeds the circuit you are working on. Select two points along the circuit through which there should have continuity. Connect one lead of the self-powered test light to each point. If there is continuity, the test light's circuit will be completed and the bulb will go on.

Jumper Wire

Use a jumper wire to bypass an open circuit. A jumper wire is made up of an in-line fuse holder connected to a set of test leads. It should have a five ampere fuse. Never use a jumper wire across any load. This direct battery short will blow the fuse.



Short Finder


Short finders are available to locate shorts to ground. The short finder creates a pulsing magnetic field in the shorted circuit and shows you the location of the short through body trim or sheet metal. Its use is explained in the following troubleshooting tests.

Troubleshooting Tests

Testing For Voltage

This test measures voltage in a circuit. When testing for voltage at a connector, you do not have to separate the two halves of the connector. Instead, probe the connector from the back. Always check both sides of the connector because dirt and corrosion between its contact surfaces can cause electrical problems.

1. Connect one lead of test light to a known good ground, or if you are using a voltmeter, be sure you connect its negative lead to ground.
2. Connect the other lead of the test light or voltmeter to the point you want to check.
3. If the test light glows, there is voltage present. If you are using a voltmeter, note the voltage reading. It should be within one volt of measured battery voltage. A loss of more than one volt indicates a problem.




How To Use This Manual

Troubleshooting Tests (cont'd)

Testing for Continuity

This test checks for continuity within a circuit. When testing for continuity at a connector, you do not have to separate the two halves of the connector. Instead, probe the connector from the back. Always check both sides of the connector because dirt and corrosion between contact surfaces can cause electrical problems.


1. Disconnect the negative cable from the car battery. If you are using an ohmmeter, hold the leads together and adjust the ohmmeter to read zero ohms.
2. Connect one lead of self-powered test light or ohmmeter to one end of the part of the circuit you wish to test.
3. Connect the other lead to the other end.
4. If the self-powered test light glows, there is continuity. If you're using an ohmmeter, low or no resistance means good continuity.




Testing For Voltage Drop

Wires, connectors, and switches are designed to conduct current with a minimum loss of voltage. A voltage drop of more than one volt indicates a problem.


1. Connect the positive lead of a voltmeter to the end of the wire (or to the side of the connector or switch) closest to the battery.
2. Connect the negative lead to the other end of the wire (or the other side of the connector or switch).
3. Turn on the components in the circuit.
4. The voltmeter will show the difference in voltage between the two points. A difference, or drop, of more than one volt indicates a problem. Check the circuit for loose or dirty connections.






Testing For A Short With A Test Light Or Voltmeter

1. Remove the blown fuse and disconnect the load.
2. Connect a test light or voltmeter across the fuse terminals. Make sure that voltage is being applied to the fuse terminals. You might have to put the ignition switch in RUN. Check the schematic to see.
3. Beginning near the fuse box, wiggle the harness. Continue this at convenient points about six inches apart while watching the test light or voltmeter.
4. When the test light blinks or the voltmeter needle moves, there is a short to ground in the wiring near that point.



Testing For A Short With A Self-Powered Test Light Or Ohmmeter.

1. Remove the blown fuse and disconnect the battery and load.
2. Connect one lead of a self-powered test light or ohmmeter to the fuse terminal on the load side.
3. Connect the other lead to a known good ground.
4. Beginning near the fuse box, wiggle the harness. Continue this at convenient points about six inches apart while watching the test light or ohmmeter.
5. If the self-powered test light blinks or the ohmmeter needle moves, there is a short to ground in the wiring near that point.





How To Use This Manual

Troubleshooting Tests (cont'd)

Testing For A Short With A Short Circuit Locator

1. Remove the blown fuse. Leave the battery connected.
2. Connect the short finder across the fuse terminals.
3. Close all switches in series in the circuit you're testing.
4. Turn on the short circuit locator. It sends pulses of current to the short. This creates a pulsing magnetic field around the wiring between the fuse box and the short.
5. Beginning at the fuse box, slowly move the short finder along the circuit wiring. The meter will show current pulses through sheet metal and body trim. As long as the meter is between the fuse and the short, the needle will move with each current pulse. Once you move the meter past the point of the short, the needle will stop moving. Check around this area to locate the cause of the short circuit.





Troubleshooting Precaution

Before Troubleshooting


- Check the main fuse and the fuse box.
- Check the battery for damage, state of charge, and clean and tight connections.
- Check alternator belt tension.

CAUTION:

- Do not quick-charge a battery unless the battery ground cable has been disconnected, or you will damage the alternator diodes.
- Do not attempt to crank the engine with the ground cable disconnected or you will severely damage the wiring.

While You're Working

- Make sure connectors are clean, and have no loose pins or receptacles.
- Make sure multiple pin connectors are packed with silicone grease.




CAUTION:

- Do not pull on the wires when disconnecting a connector, pull only on the connector housings.
- When connecting a connector, push it until it clicks into place.
- Refer to page 12 for cautions about troubleshooting circuits that contain solid-state devices.

Fuse Information


Under-Hood Relay Box



Fuse Number	Amps	Circuit Protected
19	70	Power distribution
20	40	Power distribution (ignition switch)
21	40	Power distribution (ignition switch)
22	40	Dash fuse box
23	30	Rear window defogger
24	40	Power window relay; dash fuse box
25	—	Not used
26	—	Not used
27	—	Not used
28	—	Not used
29	15	Right headlight retractor motor
30	15	Left headlight retractor motor; retractable headlight control unit; combination switch
31	15	Turn signal/hazard relay; hazard switch
32	20	Horns; brake lights; high mount brake light
33	15	Right headlight
34	15	Left headlight
35	10	PGM-FI electronic control unit; power antenna motor; cooling fan timer unit; automatic transmission control unit; stereo radio cassette player; clock
36	15	Condenser fan motor
37	10	Alternator
38	10	PGM-CARB control unit/PGM-FI main relay
39	20	Radiator fan motor




Dash Fuse Box





Fuse Number	Amps	Circuit/Component Protected
1 (Automatic)	7.5	Warning display; starter solenoid; PGM-FI electronic control unit; PGM-FI main relay; control box (PGM-CARB)
2	10	Stereo radio cassette player
3 (Manual)	—	Warning display; starter solenoid; PGM-FI electronic control unit; PGM-FI main relay; control box (PGM-CARB)
4	15	Power door lock control unit
5	15	Passenger's power window switch
6	15	Driver's power window switch
7	20	Automatic seat belt retractors
8	15	Trunk light; ignition key switch; dome light, cigarette lighter and ashtray light; integrated control unit; driver's door outer handle switch
9	15	Fog lights
10	7.5	Cruise control main switch
11	20	Sunroof relay; power windows; integrated control unit; windshield wipers; combination switch
12	10	Warning display; speed sensor amplifier; automatic transmission control unit; PGM-FI main relay; fuel cut-off relay; voltage regulator; cooling fan timer unit; emission control solenoid valves; PGM-CARB control unit
13	10	Integrated control unit; seat belt beeper/reminder assembly; shift position console switch; combination switch; back up lights switch; gauge assembly; shift lever position indicator; safety indicator; clock; gauge assembly
14	30A	Sunroof motors
15	15	Combination switch
16	—	Not used
17	15	Power mirrors; cooling fan timer unit
18	10	Rear window defogger; heater controls; A/C controls

Power Distribution

Circuit Schematic








(cont'd)

Power Distribution

Circuit Schematic (cont'd)






Power Distribution

Component Location Index

(Refer to Section 201 for photographs.)


Alternator	17	Right Headlight Retractor Relay	10
Left front of engine		Right front corner of engine compartment	
Automatic Transmission Control Unit	92	Right Horn	52
Underside of passenger's footrest		Behind right side of front bumper	
Brake Light Switch	86	Starter	41
Top of brake pedal support		Lower right front of engine	
Condenser Fan Relay	96	Turn Signal/Hazard Relay	63
In under-hood relay box		Behind left side of dash, on relay holder	
Cooling Fan Timer Unit	85	Under-Hood Relay Box	102
Below right side of dash, on kick panel		Right side of engine compartment	
Dash Fuse Box	70	C105 (4-WHT)	109
Behind left side of dash		On alternator	
Dash Relay Holder	98	C155 (3-WHT)	109
Behind left side of dash		On alternator	
Ignition Switch	87	C206 (1-BLK)	52
Right side of steering column, behind steering column covers		Behind right side of front bumper, on right horn	
Left Headlight Retractor Relay	4	C238 (8-WHT)	56
Left front corner of engine compartment		Right side of engine compartment	
Left Horn	54	C253 (17-WHT)	61
Behind left side of front bumper		On electronic control unit	
Lighting Relay	11	C255 (16-BLU)	68
In under-hood relay box		On PGM-CARB control unit	
Main Relay	100	C305 (1-BLK)	54
Behind left side of dash, on left side of dash fuse box		Behind left side of front bumper, on left horn	
PGM-CARB Control Unit	68	C411 (14-GRN)	70
Behind right side of dash		Behind left side of dash	
PGM-FI Electronic Control Unit	91	C416 (22-WHT)	78
Underside of passenger's footrest		Under left side of dash, right of steering column	
Power Antenna Motor	27	C417 (24-WHT)	78
Right side of trunk		Under left side of dash, right of steering column	
Power Window Relay	98	C421 (20-WHT)	71
Behind left side of dash, on relay holder		Behind left kick panel	
Radiator Fan Relay	96	C422 (4-WHT)	71
In under-hood relay box		Behind left kick panel	
Rear Window Defogger Relay	98	C426 (7-YEL)	72
Behind left side of dash, on relay holder		On rear of dash fuse box	
Retractable Headlight Control Unit	62	C427 (6-YEL)	72
On left kick panel		On rear of dash fuse box	
		C429 (3-YEL)	72
		On rear of dash fuse box	





C440 (16-WHT)	79
On rear of stereo radio cassette player	
C444 (4-WHT)	112
Under right side of dash	
C445 (22-WHT)	112
Under right side of dash	
C447 (3-WHT)	73
Under right side of dash	
C448 (7-WHT)	73
Under right side of dash	
C449 (18-WHT)	112
Under right side of dash	
C466 (12-WHT)	92
On automatic transmission control unit	
C486 (13-WHT)	26
Upper right side of trunk	
C501 (4-WHT) (S Model)	26
Right side of trunk	
C501 (8-WHT) (Si Model)	26
Right side of trunk	
C901 (7-WHT)	80
On front of dash fuse box	
G1	83
Lower right front of engine compartment, on frame	
T1	11
In under-hood relay box	
T2	
On starter solenoid	
T3	14
On lower right front of transmission	
T101	109
On alternator	
T102	96
In under-hood relay box	

Dash Fuse Box

Circuit Schematic








(cont'd)

Dash Fuse Box

Circuit Schematic (cont'd)







(cont'd)

Dash Fuse Box

Circuit Schematic (cont'd)





Component Location Index

(Refer to Section 201 for photographs.)


A/C Compressor Clutch Relay B 89 Right front corner of engine compartment	Heater Function Control Motor 59 Behind center of dash
A/C Compressor Control Unit 90 Behind right side of dash	Heater Recirculation Control Motor 57 Behind right side of dash
Air Vent Cut-Off Solenoid Rear of engine, near carburetors	Igniter Unit (PGM-FI) 102 Right side of engine compartment
Alternator 17 Left front of engine	Ignition Coil 15 Right rear of engine compartment
Automatic Transmission Control Unit 92 Underside of passenger's footrest	Ignition Key Switch 87 In ignition switch mechanism, behind steering column covers
Back Up Lights Switch 51 Top right side of transmission	Inner Vent Solenoid Valve 49 Center rear of engine compartment
Blower Motor 93 Below right side of dash	Integrated Control Unit 64 Behind center of dash
Condenser Fan Relay 96 In under-hood relay box	Main Relay 100 Behind left side of dash, on left side of dash fuse box
Control Box 36 Right rear of engine compartment	Neutral Safety Switch 60 Base of gear selector lever
Cooling Fan Timer Unit 85 Below right side of dash, on kick panel	PGM-CARB Control Unit 68 Behind right side of dash
Dash Fuse Box 70 Behind left side of dash	PGM-FI Electronic Control Unit 91 Underside of passenger's footrest
Dash Relay Holder 98 Behind left side of dash	Power Door Lock Control Unit 35 In passenger's door
Driver's Door Outer Handle Switch 31 In driver's door	Power Window Relay 98 Behind left side of dash, on relay holder
Driver's Seat Belt Retractors 30 In rear half of driver's door	Radio Noise Condenser 36 Right rear corner of engine compartment
Electronic Air Control Valve (EACV) (PGM-CARB) 50 Top right of engine	Rear Window Defogger Relay 98 Behind left side of dash, on relay holder
Electronic Air Control Valve (EACV) (PGM-FI) 40 Top of engine	Seat Belt Beeper/Reminder Assembly 117 Center of windshield header
Fog Light Relay 63 Behind left side of dash, on relay holder	Shift Position Console Switch 60 In console, below shift lever
Front Passenger's Seat Belt Retractors 33 In rear half of passenger's door	Speed Sensor Amplifier 107 On rear of gauge assembly
Fuel Cut-Off Relay 100 Behind left side of dash, on left side of dash fuse box	Starter Relay Behind left side of dash, on relay holder

Dash Fuse Box

Component Location Index

(Refer to Section 201 for photographs.)


Sunroof Close Relay	63	C414 (4-BLU)	78
Behind left side of dash, on relay holder		Under center of dash, near steering column	
Sunroof Open Relay	63	C415 (8-WHT)	59
Behind left side of dash, on relay holder		Behind center of dash	
Windshield Wiper Motor	2	C421 (20-WHT)	71
Left rear corner of engine compartment		Behind left kick panel	
C105 (4-WHT)	109	C423 (18-WHT)	111
On alternator		Behind right kick panel	
C111 (1-BLK)	51	C426 (7-YEL)	72
Above transmission		On rear of dash fuse box	
C155 (3-WHT)	109	C427 (6-YEL)	72
On alternator		On rear of dash fuse box	
C170 (1-BLK)	49	C428 (14-YEL)	72
Top right rear of engine		On rear of dash fuse box	
C227 (2-WHT)	15	C430 (10-YEL)	72
On ignition coil		On rear of dash fuse box	
C228 (1-BLK)	15	C431 (4-YEL)	72
In right rear corner of engine compartment		On rear of dash fuse box	
C231 (8-WHT)	115	C434 (4-WHT)	64
Left rear corner of engine compartment, near control box		Behind center of dash, on integrated control unit	
C234 (4-WHT)	36	C435 (16-BLU)	64
Right rear corner of engine compartment		Behind center of dash, on integrated control unit	
C235 (14-WHT)	16	C438 (4-WHT)	79
Right rear corner of engine compartment		Behind center of dash	
C238 (8-WHT)	56	C440 (16-WHT)	79
Right side of engine compartment		On rear of stereo radio cassette player	
C243 (14-WHT)	38	C441 (4-WHT)	93
Right front of engine compartment, behind front bumper		Under right side of dash	
C252 (20-BLK)	61	C445 (22-WHT)	112
On electronic control unit		Under right side of dash	
C255 (16-BLU)	68	C446 (23-GRN)	73
On PGM-CARB control unit		Under right side of dash	
C256 (4-RED)	58	C448 (7-WHT)	73
Behind right side of dash		Under right side of dash	
C257 (20-GRN)	58	C450 (2-WHT)	93
Behind right side of dash		Under right side of dash	
C315 (5-WHT)	2	C451 (14-WHT)	58
Left rear of engine compartment		Behind right kick panel	
		C462 (10-WHT)	60
		On center of floor, near gear selector	





C463 (2-WHT)	60
On center of floor, near gear selector	
C466 (12-WHT)	92
On automatic transmission control unit	
C485 (8-WHT)	20
In right quarter panel	
C625 (10-WHT)	28
In front half of driver's door	
C627 (4-WHT)	30
In rear half of driver's door	
C628 (4-WHT)	30
In rear half of driver's door	
C629 (4-WHT)	113
In rear half of driver's door	
C675 (6-WHT)	32
In center of passenger's door	
C677 (4-WHT)	33
In rear half of passenger's door	
C678 (4-WHT)	33
In rear half of passenger's door	
C709 (12-WHT)	81
On rear of gauge assembly	
C710 (7-YEL)	81
On rear of gauge assembly	
C711 (10-WHT)	81
On rear of gauge assembly	
C712 (14-YEL)	107
On rear of gauge assembly	
C713 (16-YEL)	81
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
C902 (1-WHT)	
Behind LH side of dash, on front of dash fuse box	
C906 (8-WHT)	80
On front of dash fuse box	
C907 (10-WHT)	80
On front of dash fuse box	

Headlight Switch

Circuit Schematic








(cont'd)

Headlight Switch

Circuit Schematic (cont'd)






Headlight Switch

Component Location Index

(Refer to Section 201 for photographs.)


Dash Fuse Box	70	C486 (13-WHT)	26
Behind left side of dash		Upper right side of trunk	
Integrated Control Unit	64	C502 (8-WHT)	23
Behind center of dash		In right rear of trunk	
Retractable Headlight Control Unit	62	C504 (4-WHT)	19
On left kick panel		Behind center of rear bumper	
C209 (3-GRN)	69	C508 (8-WHT)	25
Behind right side of front bumper		In left rear of trunk	
C304 (3-GRN)	69	C701 (4-WHT)	94
Behind left side of front bumper		Under left side of dash	
C411 (14-GRN)	70	C709 (12-WHT)	81
Behind left side of dash		On rear of gauge assembly	
C421 (20-WHT)	71	C711 (10-WHT)	81
Behind left kick panel		On rear of gauge assembly	
C426 (7-YEL)	72	C713 (16-YEL)	81
On rear of dash fuse box		On rear of gauge assembly	
C435 (16-BLU)	64	C716 (2-GRN)	77
Behind center of dash, on integrated control unit		Behind right center of dash	
C438 (4-WHT)	79	C724 (14-WHT)	80
Behind center of dash		Behind LH side of dash, on front of dash fuse box	
C440 (16-WHT)	79	C904 (9-WHT)	
On rear of stereo radio cassette player		Behind LH side of dash, on front of dash fuse box	
C445 (22-WHT)	112	C906 (8-WHT)	80
Under right side of dash		On front of dash fuse box	
C464 (2-WHT)	60	G401	74
On center of floor, near gear selector		Behind top center of dash	





Ground Distribution: G401, G402 and G471

Circuit Schematic

All wires shown are black unless otherwise designated.








(cont'd)

Ground Distribution: G401, G402 and G471

Circuit Schematic (cont'd)

All wires shown are black unless otherwise designated.







(cont'd)

Ground Distribution: G301 and G501


Circuit Schematic (cont'd)

All wires shown are black unless otherwise designated.





All wires shown are black unless otherwise designated.





(cont'd)

Ground Distribution: G201, G202, G203, G302


Circuit Schematic (cont'd)

All wires shown are black unless otherwise designated.






All wires shown are black unless otherwise designated.





(cont'd)

Ground Distribution: G101 (PGM-FI)

Circuit Schematic (cont'd)









(cont'd)

Ground Distribution: G151 (PGM-CARB), G1, G2, G3, G291, G701 and G821

Circuit Schematic (cont'd)






Ground Distribution

Component Location Index

(Refer to Section 201 for photographs.)

A/C Compressor Clutch Relay A	89	Driver's Power Door Lock Switch	
Right front corner of engine compartment		In driver's door	
A/C Compressor Clutch Relay B	89	Driver's Seat Belt Retractors	30
Right front corner of engine compartment		In rear half of driver's door	
A/C Compressor Control Unit	90	Driver's Seat Belt Switch	
Behind right side of dash		In driver's seat belt buckle	
Automatic Transmission Control Unit	92	Front Passenger's Seat Belt Retractors	33
Underside of passenger's footrest		In rear half of passenger's door	
Automatic Transmission Speed Pulser	41	Fuel Cut-Off Relay	100
On right side of transmission		Behind left side of dash, on left side of dash fuse box	
Brake Fluid Level Switch	1	Fuel Gauge Sending Unit	
Left rear of engine compartment, in brake fluid reservoir		Below rear of car, top of fuel tank	
Chime	94	Fuel Pump	
Below left side of dash		In fuel tank	
Clutch Switch A	86	Heater Function Control Motor	59
Top of clutch pedal support		Behind center of dash	
Clutch Switch B	86	Heater Recirculation Control Motor	57
Above clutch pedal support		Behind right side of dash	
Condenser Fan Motor	95	Igniter Unit (PGM-FI)	102
Left rear of radiator		Right side of engine compartment	
Control Box	36	Ignition Key Switch	87
Right rear of engine compartment		In ignition switch mechanism, behind steering column covers	
Coolant Temperature Switch A	47	Inner Vent Solenoid Valve	49
On radiator, below coolant fan		Center rear of engine compartment	
Coolant Temperature Switch B	97	Integrated Control Unit	64
Top right front of engine		Behind center of dash	
Cooling Fan Timer Unit	85	Left Door Latch Switch/Door Lock Actuator	
Below right side of dash, on kick panel		In rear half of driver's door	
Cruise Control Actuator	5	Left Door Switch	116
Left front of engine compartment		Lower section of left "B" pillar	
Cruise Control Unit	62	Left Headlight Retractor Motor	4
On left kick panel		Left front corner of engine compartment	
Dash Fuse Box	70	Left Headlight Retractor Relay	4
Behind left side of dash		Left front corner of engine compartment	
Dash Relay Holder	98	Left Primary Slow Mixture Cut-Off Solenoid Valve	
Behind left side of dash		On left carburetor	
Dimmer Relay	11	Main Relay	100
In under-hood relay box		Behind left side of dash, on left side of dash fuse box	
Driver's Door Outer Handle Switch	31		
In driver's door			




Oxygen Sensor A	7	Turn Signal/Hazard Relay	63
Center front of engine, on exhaust manifold		Behind left side of dash, on relay holder	
Oxygen Sensor B	7	Under-Hood Relay Box	102
Center front of engine, on exhaust manifold		Right side of engine compartment	
Passenger's Seat Belt Switch		Windshield Washer Motor	108
In passenger's seat belt buckle		Behind left side of bumper, below washer fluid reservoir	
PGM-CARB Control Unit	68	Windshield Wiper Motor	2
Behind right side of dash		Left rear corner of engine compartment	
PGM-FI Electronic Control Unit	91	C108 (2-WHT)	41
Underside of passenger's footrest		Lower right side of engine	
Power Antenna Motor	27	C158 (2-WHT)	41
Right side of trunk		Lower right side of engine	
Power Door Lock Control Unit	35	C175 (1-BLK)	
In passenger's door		Lower right rear of engine	
Power Steering Oil Pressure Switch	44	C201 (2-WHT)	9
Lower left rear of engine compartment		Lower right front of engine compartment	
Power Window Relay	98	C205 (6-WHT)	10
Behind left side of dash, on relay holder		Right front corner of engine compartment	
Radiator Fan Motor	9	C208 (2-RED)	66
Right rear of radiator		Behind right side of front bumper	
Radio Noise Condenser	36	C209 (3-GRN)	69
Right rear corner of engine compartment		Behind right side of front bumper	
Retractable Headlight Control Unit	62	C210 (2-WHT)	66
On left kick panel		Behind right side of front bumper	
Right Door Key Switch		C212 (2-GRN)	95
In passenger's door		Lower left front of engine compartment	
Right Door Latch Switch/Door Lock Actuator		C229 (2-WHT)	115
In rear half of passenger's door		On right side of firewall, above control box	
Right Headlight Retractor Motor	10	C231 (8-WHT)	115
Right front corner of engine compartment		Left rear corner of engine compartment, near control box	
Right Headlight Retractor Relay	10	C236 (14-WHT)	16
Right front corner of engine compartment		Right rear corner of engine compartment	
Shift Position Console Switch	60	C239 (7-WHT)	56
In console, below shift lever		Right side of engine compartment	
Speed Sensor Amplifier	107	C243 (14-WHT)	38
On rear of gauge assembly		Right front of engine compartment, behind front bumper	
Sunroof Close Relay	63	C245 (2-GRN)	105
Behind left side of dash, on relay holder		On firewall, left of control box	
TA Switch	105		
On firewall, left of control box			

Ground Distribution

Component Location Index

(Refer to Section 201 for photographs.)

C253 (17-WHT)	61	C414 (4-BLU)	78
On electronic control unit		Under center of dash, near steering column	
C255 (16-BLU)	68	C415 (8-WHT)	59
On PGM-CARB control unit		Behind center of dash	
C285 (2-GRN)	95	C423 (18-WHT)	111
Lower left front of engine compartment		Behind right kick panel	
C291 (1-BLK)	36	C424 (4-WHT)	111
Right rear corner of engine compartment		Behind right kick panel	
C302 (2-WHT)	67	C425 (6-WHT)	111
Behind left side of front bumper		Behind right kick panel	
C303 (2-RED)	67	C426 (7-YEL)	72
Behind left side of front bumper		On rear of dash fuse box	
C304 (3-GRN)	69	C434 (4-WHT)	64
Behind left side of front bumper		Behind center of dash, on integrated control unit	
C309 (6-WHT)	4	C438 (4-WHT)	79
Left front corner of engine compartment		Behind center of dash	
C311 (4-WHT)	5	C441 (4-WHT)	93
Left front of engine compartment		Under right side of dash	
C312 (2-GRN)	2	C444 (4-WHT)	112
Left rear of engine compartment, on strut tower		Under right side of dash	
G301	114	C446 (23-GRN)	73
Left front corner of engine compartment		Under right side of dash	
G302	114	C449 (18-WHT)	112
Left front corner of engine compartment		Under right side of dash	
G401	74	C451 (14-WHT)	58
Behind top center of dash		Behind right kick panel	
G402	74	C452 (4-WHT)	58
Behind top center of dash		Behind right kick panel	
G471	20	C453 (6-WHT)	58
Behind right side of rear seat		Behind right kick panel	
G501	26	C462 (10-WHT)	60
Right side of trunk		On center of floor, near gear selector	
G701	75	C466 (12-WHT)	92
Behind center dash, on center frame		On automatic transmission control unit	
G821	24	C474 (2-WHT)	
Behind left side of rear seat		Under right front seat	
C314 (1-BLK)	1	C477 (2-WHT)	22
Left rear of engine compartment		Above center of trunk	
C315 (5-WHT)	2	C487 (2-WHT)	
Left rear of engine compartment		Under driver's seat	
C411 (14-GRN)	70	C501 (4-WHT) (S Model)	26
Behind left side of dash		Right side of trunk	





C501 (8-WHT) (Si Model)	26
Right side of trunk	
C502 (8-WHT)	23
In right rear of trunk	
C504 (4-WHT)	19
Behind center of rear bumper	
C508 (8-WHT)	25
In left rear of trunk	
C624 (6-WHT)	29
In front half of driver's door	
C625 (10-WHT)	28
In front half of driver's door	
C626 (3-WHT)	28
In front half of driver's door	
C628 (4-WHT)	30
In rear half of driver's door	
C629 (4-WHT)	113
In rear half of driver's door	
C630 (6-WHT)	113
In rear half of driver's door	
C678 (4-WHT)	33
In rear half of passenger's door	
C679 (3-WHT)	34
In rear of passenger's door	
C680 (4-WHT)	34
In rear of passenger's door	
C701 (4-WHT)	94
Under left side of dash	
C702 (2-WHT)	94
Under left side of dash	
C709 (12-WHT)	81
On rear of gauge assembly	
C710 (7-YEL)	81
On rear of gauge assembly	
C711 (10-WHT)	81
On rear of gauge assembly	
C712 (14-YEL)	107
On rear of gauge assembly	
C713 (16-YEL)	81
On rear of gauge assembly	

C716 (2-GRN)	77
Behind right center of dash	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
C906 (8-WHT)	80
On front of dash fuse box	
C907 (10-WHT)	80
On front of dash fuse box	
G1	83
Lower right front of engine compartment, on frame	
G2 (PGM-CARB)	6
Left side of engine compartment, on front of strut tower	
G2 (PGM-FI)	3
Left side of engine compartment, on front of strut tower	
G3	76
Center rear of engine compartment, on firewall	
G101	8
On top right side of engine	
G151	110
On top right front of engine	
G201	12
Right side of engine compartment	
G202	12
Right side of engine compartment	
G203	16
On right rear of engine compartment	
G291 (PGM-CARB)	110
On underside of distributor	
G291 (PGM-FI)	46
On rear of distributor	
T3	14
On lower right front of transmission	
T4 (PGM-CARB)	6
On top left front of engine	
T4 (PGM-FI)	3
On top left front of engine	
T5	3
On top left front of engine	
T6	76
On rear of engine	

Ignition System: PGM-CARB

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Distributor	99
Top right side of engine	
Igniter Unit (PGM-CARB)	50
In distributor, under side cover	
Ignition Coil	15
Right rear of engine compartment	
Ignition Switch	87
Right side of steering column, behind steering column covers	
PGM-CARB Control Unit	68
Behind right side of dash	
Radio Noise Condenser	36
Right rear corner of engine compartment	
C227 (2-WHT)	15
On ignition coil	
C228 (1-BLK)	15
In right rear corner of engine compartment	
C254 (16-YEL)	68
On PGM-CARB control unit	
C256 (4-RED)	58
Behind right side of dash	
C257 (20-GRN)	58
Behind right side of dash	
C291 (1-BLK)	36
Right rear corner of engine compartment	
C431 (4-YEL)	72
On rear of dash fuse box	
C448 (7-WHT)	73
Under right side of dash	
C901 (7-WHT)	80
On front of dash fuse box	
G291 (PGM-CARB)	110
On underside of distributor	
G291 (PGM-FI)	46
On rear of distributor	


How The Circuit Works


With the ignition switch in RUN or START, voltage is applied to the ignition coil and the solid-state igniter in the distributor. As the distributor shaft turns, the igniter acts as a switch to control current flow through the primary winding of the ignition coil. When current flow through the primary winding is stopped, a high-voltage current is induced in the secondary winding of the ignition coil. The high-voltage current flows through the distributor cap and rotor to the proper spark plug.

The radio noise condenser helps suppress electrical radio interference.

Ignition System: PGM-FI

Circuit Schematic





Component Location Index


(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Igniter Unit (PGM-FI).	102
Right side of engine compartment	
Ignition Coil	15
Right rear of engine compartment	
Ignition Switch	87
Right side of steering column, behind steering column covers	
PGM-FI Electronic Control Unit.	91
Underside of passenger's footrest	
Radio Noise Condenser	36
Right rear corner of engine compartment	
TDC/Crank Sensor	99
In distributor	
C121 (4-WHT).	18
Top right side of engine, near distributor	
C226 (2-WHT)	15
On ignition coil	
C227 (2-WHT)	15
On ignition coil	
C228 (1-BLK)	15
In right rear corner of engine compartment	
C252 (20-BLK)	61
On electronic control unit	
C256 (4-RED)	58
Behind right side of dash	
C291 (1-BLK)	36
Right rear corner of engine compartment	
C431 (4-YEL)	72
On rear of dash fuse box	
C448 (7-WHT)	73
Under right side of dash	
C901 (7-WHT)	80
On front of dash fuse box	
G203	16
On right rear of engine compartment	
G291 (PGM-CARB).	110
On underside of distributor	
G291 (PGM-FI).	46
On rear of distributor	

How The Circuit Works


With the ignition switch in RUN or START, voltage is applied to the ignition coil. As the distributor shaft turns, the igniter acts as a switch to control current flow through the primary winding of the ignition coil. When current flow through the primary winding is stopped, a high-voltage current is induced in the secondary winding of the ignition coil. The high-voltage current flows through the distributor cap and rotor to the proper spark plug.


The radio noise condenser helps suppress electrical radio interference.



Starting System

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Clutch Switch B	86
Above clutch pedal support	
Dash Fuse Box	70
Behind left side of dash	
Ignition Switch	87
Right side of steering column, behind steering column covers	
Neutral Safety Switch	60
Base of gear selector lever	
Starter	41
Lower right front of engine	
Starter Relay	
Behind left side of dash, on relay holder	
Under-Hood Relay Box	102
Right side of engine compartment	
C238 (8-WHT)	56
Right side of engine compartment	
C429 (3-YEL)	72
On rear of dash fuse box	
C431 (4-YEL)	72
On rear of dash fuse box	
C448 (7-WHT)	73
Under right side of dash	
C463 (2-WHT)	60
On center of floor, near gear selector	
C901 (7-WHT)	80
On front of dash fuse box	
G1	83
Lower right front of engine compartment, on frame	
G401	74
Behind top center of dash	
T1	11
In under-hood relay box	
T2	
On starter solenoid	
T3	14
On lower right front of transmission	


How The Circuit Works


Voltage is applied at all times from the positive battery terminal to the ignition switch and the normally open starter solenoid contacts. When the ignition switch is turned to START and the neutral safety switch (automatic transmission) is closed, voltage is applied to the starter solenoid coil. The starter solenoid coil energizes, the starter solenoids contacts close, and voltage is applied to the starter motor. The starter motor engages to start the engine.

With a manual transmission voltage is applied to the starter relay coil when the ignition switch is turned to start and clutch switch B is closed, the starter relay coil energizes the starter relay contacts allowing voltage to be applied to the starter solenoid coil which energizes the starter solenoid contacts. Voltage is then applied to the starter and engaging it to start the engine.

Charging System

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Alternator	17
Left front of engine	
Dash Fuse Box	70
Behind left side of dash	
PGM-FI Electronic Control Unit	91
Underside of passenger's footrest	
Under-Hood Relay Box	102
Right side of engine compartment	
C105 (4-WHT)	109
On alternator	
C155 (3-WHT)	109
On alternator	
C235 (14-WHT)	16
Right rear corner of engine compartment	
C238 (8-WHT)	56
Right side of engine compartment	
C252 (20-BLK)	61
On electronic control unit	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C428 (14-YEL)	72
On rear of dash fuse box	
C445 (22-WHT)	112
Under right side of dash	
C712 (14-YEL)	107
On rear of gauge assembly	
G1	83
Lower right front of engine compartment, on frame	
T1	11
In under-hood relay box	
T3	14
On lower right front of transmission	
T101	109
On alternator	
T102	96
In under-hood relay box	

How The Circuit Works

The alternator supplies DC voltage to operate the vehicle's electrical systems and to recharge its battery. The output of the alternator is controlled by the built-in voltage regulator.

When you first move the ignition switch to RUN, before the engine is started, voltage is applied to the charge warning light through fuse 12. The charge warning light is grounded through terminal L of the alternator, and it goes on.

With the engine running and the alternator operating normally, voltage is still applied to the charge warning light through fuse 12 but now voltage is also applied from the alternator (terminal L). With equal voltage on both sides of the charge warning light, the light does not go on.

When the engine is running and the alternator is not charging, the charge warning light is grounded through the alternator (terminal L): The charge warning light goes on to warn the driver that the alternator is not charging properly.

Charging System

Quick Checks

1. Check that the battery is not damaged by observing the case for cracks or loose posts.
2. Check that the battery is fully charged by observing the battery indicator:


Blue or Green — OK
Red — add distilled water
Clear — needs charging

Note: If battery indicator is Red or Clear, see Section 23 of the Service Manual for battery test procedures.

3. Check fuses 12, 19 and 37 by visual inspection.
4. Check alternator belt tension. See Section 23 of the Service Manual for alternator belt adjustment.
5. Refer to Section 11 of the Service Manual for Alternator FR Signal test procedures.

Troubleshooting

Symptom	Troubleshoot
Charge warning light does not light with the ignition switch in RUN.	A
Battery is undercharged or charge warning light is ON with engine running.	B
Interior and exterior lights intensify or dim depending on engine rpm.	C



Troubleshooting A

Charge warning light does not light with ignition switch in RUN.

Turn the ignition switch off.

Disconnect alternator connector C105 or C155.

Connect fused jumper between the WHT/BLU wire terminal of connector and ground.

Turn the ignition switch to RUN.

Is charge warning light on?

YES

NO

- Check for a defective:
- fuse 9
 - charge warning bulb
 - BLK/YEL wire between dash fuse box and gauge assembly
 - WHT/BLU wires between gauge assembly and alternator
 - dash function box
 - gauge assembly




(To page 22-6)

(cont'd)


Charging System

Troubleshooting (cont'd)


Troubleshooting B



(Continued on facing page)



(Continued from facing page)




(cont'd)


Charging System

Troubleshooting (cont'd)

Troubleshoot C



(Continued on facing page)



(Continued from facing page)

Start engine and turn on the headlights, blower motor, rear window defogger and other electrical systems until the voltage is below 13.5V. If voltage exceeds 15V, stop engine and replace the voltage regulator. See Section 23 of the Service Manual.

Compare the readings to the chart.

Is output within specification when voltage is between 13.9V and 15.1V?

NO

YES

Turn off all electrical loads.

Measure voltage at 1500 RPM.

Is voltage between 13.9V and 15.1V?

YES

Alternator and regulator are good.

NO

Perform a full field test: Insert a short screwdriver into the brush holder screw hole in the alternator and cover.

With the screwdriver touching the brush screw, ground the screwdriver with a jumper lead to a clean ground.

Compare the amperage readings to the chart.


Is the reading within specification?

NO

Replace the alternator. See Section 23 of the Service Manual.

YES


Replace the voltage regulator. See Section 23 of the Service Manual.





PGM-CARB

Circuit Schematic

* Automatic Transmission
 ** Manual Transmission








(cont'd)

PGM-CARB

Circuit Schematic (cont'd)






PGM-CARB

Component Location Index

(Refer to Section 201 for photographs.)

A/C Compressor Control Unit	90	Oxygen Sensor	53
Behind right side of dash		Lower front of engine	
Air Leak Solenoid Valve	49	PGM-CARB Control Unit	68
Center rear of engine compartment		Behind right side of dash	
Air Suction Control Solenoid Valve	48	Purge Cut-Off Solenoid Valve	104
In control box		In control box	
Air Vent Cut-Off Solenoid		Right Primary Slow Mixture Cut-Off Solenoid	
Rear of engine, near carburetors		Valve	49
Automatic Transmission Control Unit	92	On right carburetor	
Underside of passenger's footrest		Speed Sensor Amplifier	107
Clutch Switch A	86	On rear of gauge assembly	
Top of clutch pedal support		Under-Hood Relay Box	102
Control Box	36	Right side of engine compartment	
Right rear of engine compartment		Vacuum Piston Control Solenoid Valve	48
Coolant Temperature Sensor (TW)	97	In control box	
Top right front of engine		Vacuum Switch	104
Cranking Leak Solenoid Valve	48	In control box	
In control box		C163 (1-WHT)	53
Cruise Control Unit	62	Lower front of engine	
On left kick panel		C169 (1-BLK)	49
Dash Fuse Box	70	Top right rear of engine	
Behind left side of dash		C170 (1-BLK)	49
Electronic Air Control Valve (EACV) (PGM-CARB)	50	Top right rear of engine	
Top right of engine		C171 (1-BLK)	49
Fuel Cut-Off Relay	100	Top right rear of engine	
Behind left side of dash, on left side of dash fuse box		C174	
Fuel Pump		Lower left rear of engine compartment	
In fuel tank		C175 (1-BLK)	
Idle Boost Solenoid Valve	105	Lower right rear of engine	
Right rear of engine compartment, on firewall		C176 (1-BLK)	
Ignition Coil	15	Lower right rear of engine	
Right rear of engine compartment		C227 (2-WHT)	15
Inner Vent Solenoid Valve	49	On ignition coil	
Center rear of engine compartment		C230 (3-WHT)	115
Intake Air Temperature (TA) Sensor (PGM-CARB)	84	On front of control box	
Top rear of engine		C231 (8-WHT)	115
Left Primary Slow Mixture Cut-Off Solenoid Valve		Left rear corner of engine compartment, near control box	
On left carburetor		C238 (8-WHT)	56
		Right side of engine compartment	
		C239 (7-WHT)	56
		Right side of engine compartment	



C241 (6-YEL)	56
Right side of engine compartment	
C242 (1-WHT)	
Right side of engine compartment	
C254 (16-YEL)	68
On PGM-CARB control unit	
C255 (16-BLU)	68
On PGM-CARB control unit	
C257 (20-GRN).	58
Behind right side of dash	
C417 (24-WHT).	78
Under left side of dash, right of steering column	
C418 (10-BLU)	78
Under left side of dash, right of steering column	
C426 (7-YEL)	72
On rear of dash fuse box	
C428 (14-YEL)	72
On rear of dash fuse box	
C444 (4-WHT)	112
Under right side of dash	
C445 (22-WHT).	112
Under right side of dash	
C446 (23-GRN).	73
Under right side of dash	
C467 (18-WHT).	92
On automatic transmission control unit	
C710 (7-WHT), C711 (10-WHT)	81
On rear of gauge assembly	
C712 (14-YEL)	107
On rear of gauge assembly	
C724 (14-WHT).	80
Behind LH side of dash, on front of dash fuse box	
G151	110
On top right front of engine	
G202	12
Right side of engine compartment	
G203	16
On right rear of engine compartment	
G401	74
Behind top center of dash	
G471	20
Behind right side of rear seat	

How The Circuit Works


The PGM-CARB system provides the correct air-fuel ratio based on engine speed and absolute pressure in the manifold.



The electronic control unit and various sensors provide extremely accurate control of air-fuel mixture under all operating conditions.

See Section 11 of the Service Manual for circuit description and troubleshooting procedures.

PGM-FI


Circuit Schematic







PGM-FI

Circuit Schematic (cont'd)








(cont'd)

PGM-FI

Circuit Schematic (cont'd)








(cont'd)

PGM-FI

Circuit Schematic (cont'd)








(cont'd)

PGM-FI

Circuit Schematic (cont'd)






PGM-FI

Component Location Index

(Refer to Section 201 for photographs.)

Atmosphere Pressure (PA) Sensor 91	PGM-FI Electronic Control Unit 91
Underside of passenger's footrest	Underside of passenger's footrest
Automatic Transmission Control Unit 92	Power Steering Oil Pressure Switch 44
Underside of passenger's footrest	Lower left rear of engine compartment
Bypass Control Solenoid Valve 37	Shift Position Console Switch 60
In control box	In console, below shift lever
Control Box 36	Speed Sensor Amplifier 107
Right rear of engine compartment	On rear of gauge assembly
Coolant Temperature Sensor (TW) 97	TDC/Crank Sensor 99
Top right front of engine	In distributor
CYL Sensor 39	Throttle Angle Sensor (PGM-FI) 43
Upper right end of engine	Top rear of engine
Dash Fuse Box 70	Under-Hood Relay Box 102
Behind left side of dash	Right side of engine compartment
Distributor 99	C113 (1-WHT) 7
Top right side of engine	Center front of engine
EGR Control Solenoid Valve 37	C118 (1-GRN) 7
In control box	Center front of engine
EGR Valve Lift Sensor 18	C119 (2-WHT) 39
Top right rear of engine	Top right side of engine
Electronic Air Control Valve (EACV) (PGM-FI) . . 40	C121 (4-WHT) 18
Top of engine	Top right side of engine, near distributor
Fuel Injector Resistors 101	C122 (3-WHT) 18
Center rear of engine compartment, on firewall	Top right side of engine, near distributor
Fuel Injectors 40	C128 (6-WHT) 101
Top of engine, in intake manifold	Left rear of engine compartment, on firewall
Fuel Pump	C232 (2-WHT) 16
In fuel tank	Right rear corner of engine compartment
Ignition Timing Adjusting Connector 16	C233 (3-WHT) 16
In right rear corner of engine compartment	Right rear corner of engine compartment
Intake Air Temperature (TA) Sensor (PGM-FI) . . 45	C234 (4-WHT) 36
Left rear of engine	Right rear corner of engine compartment
Main Relay 100	C235 (14-WHT) 16
Behind left side of dash, on left side of dash fuse box	Right rear corner of engine compartment
Manifold Absolute Pressure (MAP) Sensor 37	C236 (14-WHT) 16
In control box	Right rear corner of engine compartment
Oxygen Sensor A 7	C238 (8-WHT) 56
Center front of engine, on exhaust manifold	Right side of engine compartment
Oxygen Sensor B 7	C251 (16-BLK) 61
Center front of engine, on exhaust manifold	On electronic control unit
	C252 (20-BLK) 61
	On electronic control unit



C253 (17-WHT)	61
On electronic control unit	
C257 (20-GRN)	58
Behind right side of dash	
C312 (2-GRN)	2
Left rear of engine compartment, on strut tower	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C418 (10-BLU)	78
Under left side of dash, right of steering column	
C421 (20-WHT)	71
Behind left kick panel	
C428 (14-YEL)	72
On rear of dash fuse box	
C444 (4-WHT)	112
Under right side of dash	
C445 (22-WHT)	112
Under right side of dash	
C446 (23-GRN)	73
Under right side of dash	
C449 (18-WHT)	112
Under right side of dash	
C462 (10-WHT)	60
On center of floor, near gear selector	
C467 (18-WHT)	92
On automatic transmission control unit	
C710 (7-YEL)	81
On rear of gauge assembly	
C711 (10-WHT)	81
On rear of gauge assembly	
C712 (14-YEL)	107
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
G101	8
On top right side of engine	
G301	114
Left front corner of engine compartment	
G401	74
Behind top center of dash	
G701	75
Behind center dash, on center frame	

How The Circuit Works


The PGM-FI system provides the correct air-fuel ratio based on engine speed and absolute pressure in the manifold.


The electronic control unit and various sensors provide extremely accurate control of air-fuel mixture under all operating conditions. At the precise time a piston is on the intake stroke, fuel is injected into the correct intake manifold runner.

See Section 11 of the Service Manual for circuit description and troubleshooting procedures.

Speed Sensor

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)


Automatic Transmission Control Unit	92
Underside of passenger's footrest	
Cruise Control Unit	62
On left kick panel	
Dash Fuse Box	70
Behind left side of dash	
Integrated Control Unit	64
Behind center of dash	
PGM-CARB Control Unit	68
Behind right side of dash	
PGM-FI Electronic Control Unit	91
Underside of passenger's footrest	
Speed Sensor Amplifier	107
On rear of gauge assembly	
C252 (20-BLK)	61
On electronic control unit	
C254 (16-YEL)	68
On PGM-CARB control unit	
C416 (22-WHT)	78
Under left side of dash, right of steering column	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C435 (16-BLU)	64
Behind center of dash, on integrated control unit	
C444 (4-WHT)	112
Under right side of dash	
C449 (18-WHT)	112
Under right side of dash	
C467 (18-WHT)	92
On automatic transmission control unit	
C710 (7-YEL)	81
On rear of gauge assembly	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
G701	75
Behind center dash, on center frame	



How The Circuit Works

The speed sensor generates a signal that indicates the speed of the car. The speed sensor amplifier receives this signal and applies it to the integrated control unit and other equipped control units. This signal is then used by each control unit to perform the necessary functions required by each circuit.

Cruise Control: PGM-FI

Circuit Schematic







(cont'd)

Cruise Control: PGM-FI

Circuit Schematic (cont'd)





Component Location Index

(Refer to Section 201 for photographs.)

Brake Light Switch	86	C306 (1-BLK)	54
Top of brake pedal support		Behind left side of front bumper, on left horn	
Clutch Switch A	86	C311 (4-WHT)	5
Top of clutch pedal support		Left front of engine compartment	
Cruise Control Actuator	5	C411 (14-GRN)	70
Left front of engine compartment		Behind left side of dash	
Cruise Control Unit	62	C417 (24-WHT)	78
On left kick panel		Under left side of dash, right of steering column	
Dash Fuse Box	70	C419 (8-WHT)	78
Behind left side of dash		Under left side of dash, right of steering column	
Horn Slip Ring		C420 (13-WHT)	71
On underside of steering wheel		Behind left kick panel	
Igniter Unit (PGM-FI)	102	C421 (20-WHT)	71
Right side of engine compartment		Behind left kick panel	
Ignition Coil	15	C422 (4-WHT)	71
Right rear of engine compartment		Behind left kick panel	
Left Horn	54	C444 (4-WHT)	112
Behind left side of front bumper		Under right side of dash	
Right Horn	52	C445 (22-WHT)	112
Behind right side of front bumper		Under right side of dash	
Shift Position Console Switch	60	C462 (10-WHT)	60
In console, below shift lever		On center of floor, near gear selector	
Speed Sensor Amplifier	107	C710 (7-YEL)	81
On rear of gauge assembly		On rear of gauge assembly	
Under-Hood Relay Box	102	C712 (14-YEL)	107
Right side of engine compartment		On rear of gauge assembly	
C206 (1-BLK)	52	C723 (4-WHT)	94
Behind right side of front bumper, on right horn		Under left side of dash, on dash fuse box	
C207 (1-BLK)	52	G302	114
Behind right side of front bumper, on right horn		Left front corner of engine compartment	
C226 (2-WHT)	15	G401	74
On ignition coil		Behind top center of dash	
C227 (2-WHT)	15	G471	20
On ignition coil		Behind right side of rear seat	
C305 (1-BLK)	54	G701	75
Behind left side of front bumper, on left horn		Behind center dash, on center frame	

Cruise Control

How The Circuit Works

The cruise control system uses mechanical, electrical, and vacuum operated devices to maintain vehicle speed at a setting selected by the driver.

System Description

The cruise control unit receives command signals from the cruise control main switch and the cruise control set/resume switch. The cruise control unit receives information about operating conditions from the brake switch, the distributor, the speed sensor, the clutch switch (manual transmission), or the shift position console switch (automatic transmission). The cruise control unit sends operational signals to the cruise control actuator valves that regulate the throttle position. The throttle position maintains the selected vehicle speed. Essentially, the control unit compares the actual speed of the vehicle to the selected speed. Then, the control unit uses the result of that comparison to open or close the throttle.


The brake switch releases the system's control of the throttle at the instant the driver depresses the brake pedal. The switch sends an electronic signal to the control unit when the brake pedal is depressed; the control unit responds by allowing the throttle to close. The clutch switch (manual transmission) or the shift position console switch (automatic transmission) sends a disengage signal input to the control unit that also allows the throttle to close.

The cruise control system will set and automatically maintain any speed above 30 mph (45 kph). To set, make sure that the main switch is ON. After reaching the desired speed, press the set switch. The cruise control unit receives a set signal input and, in turn, actuates the cruise control vacuum valves.

When the set switch is depressed and the cruise control system is on, the "Cruise Control" indicator on the warning display lights up.


You can cancel the cruise control system by pushing the main switch off. This removes power to the control unit and erases the set speed from memory. If the system is disengaged temporarily by the brake switch, clutch switch, or shift position console switch and vehicle speed is still above 30 mph, press the resume switch. With the resume switch depressed and the set memory retained, the vehicle automatically returns to the previously set speed.



For gradual acceleration without depressing the accelerator pedal, push the resume switch down and hold it there until the desired speed is reached. This will send an acceleration signal input to the control unit. When the switch is released, the system will be reprogrammed for the new speed. To slow the vehicle down, depress the set switch. This sends a deceleration signal input to the control unit causing the vehicle to coast until the desired speed is reached. When the desired speed is reached, release the set switch. This reprograms the system for the new speed.



Automatic Transmission Controls: PGM-CARB


Circuit Schematic







Automatic Transmission Controls: PGM-CARB

Circuit Schematic (cont'd)







(cont'd)

Automatic Transmission Controls: PGM-CARB

Circuit Schematic (cont'd)





Component Location Index

(Refer to Section 201 for photographs.)

Automatic Transmission Control Unit	92	C158 (2-WHT)	41
Underside of passenger's footrest		Lower right side of engine	
Automatic Transmission Speed Pulser	41	C159 (2-WHT)	42
On right side of transmission		Lower right front of engine	
Brake Light Switch	86	C160 (2-WHT)	42
Top of brake pedal support		Lower right front of engine	
Coolant Temperature Sensor (TW)	97	C238 (8-WHT)	56
Top right front of engine		Right side of engine compartment	
Dash Fuse Box	70	C239 (7-WHT)	56
Behind left side of dash		Right side of engine compartment	
Distributor	99	C240 (6-WHT)	56
Top right side of engine		Right side of engine compartment	
Ignition Coil	15	C254 (16-YEL)	68
Right rear of engine compartment		On PGM-CARB control unit	
Lock-Up Control Solenoid Valve	103	C255 (16-BLU)	68
Right front of transmission		On PGM-CARB control unit	
PGM-CARB Control Unit	68	C257 (20-GRN)	58
Behind right side of dash		Behind right side of dash	
Shift Control Solenoid Valve	103	C417 (24-WHT)	78
Right front of transmission		Under left side of dash, right of steering column	
Shift Position Console Switch	60	C418 (10-BLU)	78
In console, below shift lever		Under left side of dash, right of steering column	
Speed Sensor Amplifier	107	C426 (7-YEL)	72
On rear of gauge assembly		On rear of dash fuse box	
Throttle Angle Sensor (PGM-CARB)		C428 (14-YEL)	72
On right carburetor		On rear of dash fuse box	
Under-Hood Relay Box	102	C444 (4-WHT)	112
Right side of engine compartment		Under right side of dash	
C157 (3-WHT)		C445 (22-WHT)	112
Center rear of engine		Under right side of dash	

Automatic Transmission Controls: PGM-CARB

Component Location Index

(Refer to Section 201 for photographs.)


C446 (23-GRN)	73
Under right side of dash	
C462 (10-WHT)	60
On center of floor, near gear selector	
C466 (12-WHT)	92
On automatic transmission control unit	
C467 (18-WHT)	92
On automatic transmission control unit	
C710 (7-YEL)	81
On rear of gauge assembly	
C711 (10-WHT)	81
On rear of gauge assembly	
C713 (16-YEL)	81
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
G151	110
On top right front of engine	
G401	74
Behind top center of dash	
G471	20
Behind right side of rear seat	

How The Circuit Works

The automatic transmission is a combination of a three element torque converter and a dual-shaft electronically controlled automatic transmission which provides four forward speeds and one reverse speed. The entire unit is positioned in line with the engine.


The electronic control system consists of an automatic transmission control unit, sensors, and four solenoid valves. Shifting and lock-up are electronically controlled for comfortable driving under all conditions.



See Section 14 of the Service Manual for circuit description and troubleshooting procedures.



Automatic Transmission Controls: PGM-FI

Circuit Schematic








(cont'd)

Automatic Transmission Controls: PGM-FI

Circuit Schematic (cont'd)







(cont'd)

Automatic Transmission Controls: PGM-FI

Circuit Schematic (cont'd)





Component Location Index

(Refer to Section 201 for photographs.)

Automatic Transmission Control Unit 92 Underside of passenger's footrest	C109 (2-WHT) 42 Lower right front of engine
Automatic Transmission Speed Pulser 41 On right side of transmission	C110 (2-WHT) 42 Lower right front of engine
Brake Light Switch 86 Top of brake pedal support	C227 (2-WHT) 15 On ignition coil
Coolant Temperature Sensor (TW) 97 Top right front of engine	C235 (14-WHT) 16 Right rear corner of engine compartment
Dash Fuse Box 70 Behind left side of dash	C236 (14-WHT) 16 Right rear corner of engine compartment
Distributor 99 Top right side of engine	C237 (3-WHT) 13 Right side of engine compartment
Ignition Coil 15 Right rear of engine compartment	C238 (8-WHT) 56 Right side of engine compartment
Lock-Up Control Solenoid Valve 103 Right front of transmission	C251 (16-BLK) 61 On electronic control unit
PGM-FI Electronic Control Unit 91 Underside of passenger's footrest	C252 (20-BLK) 61 On electronic control unit
Shift Control Solenoid Valve 103 Right front of transmission	C257 (20-GRN) 58 Behind right side of dash
Shift Position Console Switch 60 In console, below shift lever	C417 (24-WHT) 78 Under left side of dash, right of steering column
Speed Sensor Amplifier 107 On rear of gauge assembly	C418 (10-BLU) 78 Under left side of dash, right of steering column
Throttle Angle Sensor (PGM-FI) 43 Top rear of engine	C426 (7-YEL) 72 On rear of dash fuse box
Under-Hood Relay Box 102 Right side of engine compartment	C428 (14-YEL) 72 On rear of dash fuse box
C108 (2-WHT) 41 Lower right side of engine	C444 (4-WHT) 112 Under right side of dash


Automatic Transmission Controls: PGM-FI


How The Circuit Works

The automatic transmission is a combination of the element torque converter and a dual-shaft electronically controlled automatic transmission which provides four forward speeds and one reverse speed. The entire unit is positioned in line with the engine.

The electronic control system consists of an automatic transmission control unit, sensors, and four solenoid valves. Shifting and lock-up are electronically controlled for comfortable driving under all conditions.


See Section 14 of the Service Manual for circuit description and troubleshooting procedures.






Horns

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)


Left Horn	54
Behind left side of front bumper	
Under-Hood Relay Box	102
Right side of engine compartment	
C206 (1-BLK)	52
Behind right side of front bumper, on right horn	
C207 (1-BLK)	52
Behind right side of front bumper, on right horn	
C305 (1-BLK)	54
Behind left side of front bumper, on left horn	
C306 (1-BLK)	54
Behind left side of front bumper, on left horn	
C411 (14-GRN)	70
Behind left side of dash	
C421 (20-WHT)	71
Behind left kick panel	
C422 (4-WHT)	71
Behind left kick panel	
C444 (4-WHT)	112
Under right side of dash	
C445 (22-WHT)	112
Under right side of dash	

How The Circuit Works

Voltage is applied at all times through fuse 32 to the left and right horns. The circuit continues from the horns to the slip ring or contact ring and to the horn switch. When the horn switch is closed, the circuit path is completed to ground: The horns sound.

Rear Window Defogger

Circuit Schematic



Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Dash Relay Holder	98
Behind left side of dash	
Radio Noise Condenser	
Below left side of dash, on kick panel	
Radio Noise Filter	27
Right rear of trunk	
Rear Window Defogger Relay	98
Behind left side of dash, on relay holder	
Under-Hood Relay Box	102
Right side of engine compartment	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C426 (7-YEL)	72
On rear of dash fuse box	
C430 (10-YEL)	72
On rear of dash fuse box	
C432 (1-BLK)	
At left kick panel	
C448 (7-WHT)	73
Under right side of dash	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
G471	20
Behind right side of rear seat	
G821	24
Behind left side of rear seat	


How The Circuit Works


Voltage is applied at all times through fuse 23 to the rear window defogger relay. With the ignition switch in RUN, voltage is applied through fuse 18 to the rear window defogger relay coil and the defogger ON indicator.

When you turn the rear window defogger switch to ON, a path to ground is provided for the rear window defogger relay coil and the defogger ON indicator. The defogger ON indicator lights up and the rear window defogger relay contact closes. Voltage is applied to the defogger grid on the surface of the rear window: The grid heats the rear window to remove any fog from the glass.

A/C: Blower Control

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)


Blower Motor	93
Below right side of dash	
Blower Resistor	90
Behind right side of dash	
Dash Fuse Box	70
Behind left side of dash	
Ignition Switch	87
Right side of steering column, behind steering column covers	
C431 (4-YEL)	72
On rear of dash fuse box	
C450 (2-WHT)	93
Under right side of dash	
C901 (7-WHT)	80
On front of dash fuse box	
G401	74
Behind top center of dash	

How The Circuit Works

The blower motor speed is controlled by the heater fan switch in the heater control panel. With the ignition switch in RUN and the heater fan switch in position 1, all the blower resistors are in the circuit with the motor so the motor runs slowly. In positions 2 and 3, the heater fan switch bypasses some of the resistors, increasing the speed of the blower motor.


When the heater fan switch is in position 4, all the blower resistors are bypassed and full battery voltage is applied across the blower motor: The motor runs at maximum speed.


With the heater fan switch off the circuit is open and no voltage is applied across the blower motor. The motor does not run.




A/C: Fans and Compressor Controls (PGM-CARB)

Circuit Schematic







*Standard A/C
**Optional A/C



A/C: Fans and Compressor Controls (PGM-CARB)

Circuit Schematic (cont'd)





Component Location Index

(Refer to Section 201 for photographs.)

A/C Compressor Clutch	17	C201 (2-WHT)	9
Lower left front of engine		Lower right front of engine compartment	
A/C Compressor Clutch Relay A	89	C212 (2-GRN)	95
Right front corner of engine compartment		Lower left front of engine compartment	
A/C Compressor Clutch Relay B	89	C213 (4-WHT)	
Right front corner of engine compartment		Lower left front of engine compartment, near A/C compressor	
A/C Compressor Control Unit	90	C229 (2-WHT)	115
Behind right side of dash		On right side of firewall, above control box	
A/C Diodes	38	C243 (14-WHT)	38
Right front of car, behind bumper		Right front of engine compartment, behind front bumper	
A/C Pressure Switch	5	C245 (2-GRN)	105
Lower left front corner of engine compartment, on receiver		On firewall, left of control box	
Condenser Fan Motor	95	C254 (16-YEL)	68
Left rear of radiator		On PGM-CARB control unit	
Condenser Fan Relay	96	C255 (16-BLU)	68
In under-hood relay box		On PGM-CARB control unit	
Coolant Temperature Switch A	47	C284 (2-WHT)	
On radiator, below coolant fan		Lower left front of engine compartment, near A/C compressor	
Cooling Fan Timer Unit	85	C285 (2-GRN)	95
Below right side of dash, on kick panel		Lower left front of engine compartment	
Dash Fuse Box	70	C286 (2-WHT)	5
Behind left side of dash		Lower left front of engine compartment, on A/C pressure switch	
Evaporator Sensor	65	C310 (2-WHT)	5
Behind dash, at evaporator		Lower left front of engine compartment, on A/C pressure switch	
Idle Boost Solenoid Valve	105	C421 (20-WHT)	71
Right rear of engine compartment, on firewall		Behind left kick panel	
PGM-CARB Control Unit	68	C428 (14-YEL)	72
Behind right side of dash		On rear of dash fuse box	
Radiator Fan Motor	9	C430 (10-YEL)	72
Right rear of radiator		On rear of dash fuse box	
Radiator Fan Relay	96	C445 (22-WHT)	112
In under-hood relay box		Under right side of dash	
TA Switch	105		
On firewall, left of control box			
Under-Hood Relay Box	102		
Right side of engine compartment			

A/C: Fans and Compressor Controls (PGM-CARB)

Component Location Index

(Refer to Section 201 for photographs.)

C446 (23-GRN)	73
Under right side of dash	
C449 (18-WHT)	112
Under right side of dash	
G201	12
Right side of engine compartment	
G202	12
Right side of engine compartment	
G203	16
On right rear of engine compartment	
G401	74
Behind top center of dash	

How The Circuit Works

Fans

The cooling fan timer unit operates the radiator and condenser fans according to the temperature of the engine coolant. Both fans are turned on when the coolant temperature rises above 194°F (90°C) and are turned off when the coolant temperature falls below 181°F (83°C). If the engine coolant temperature is above 226°F (108°C) when the ignition is turned off, the cooling fan timer will run the condenser fan for a maximum of 15 minutes or until the engine coolant temperature drops to 214°F (101°C). The cooling fan timer unit controls the fans by operating the radiator and condenser fan relays.


Closure of coolant temperature switch A initiates the operation of both fans at 194°F (90°C). Closure of coolant temperature switch B affects only the condenser fan and is used for initiating operation of the condenser fan at ignition turn-off.

Compressor Control

When the A/C switch and the blower switch are turned on, a ground is applied from the heater control panel through the evaporator sensor, the A/C pressure switch and the A/C diodes to the cooling fan timer unit and the PGM-FI electronic control unit. The cooling fan timer unit energizes both fans. The electronic control unit increases the engine idle speed and signals the A/C compressor control unit to operate compressor clutch relays A and B, which will engage the A/C compressor clutch.


When the evaporator temperature drops below 37°F (3°C), the evaporator sensor opens its contacts, removing the ground from the cooling fan timer and electronic control unit. Both cooling fans and the A/C compressor clutch are de-energized until the evaporator temperature rises to a point where additional cooling is required. The evaporator sensor then closes its contacts and the cycle is repeated.



If refrigerant pressure becomes too high due to blockage or too low due to leakage, the A/C pressure switch contacts open, which interrupts the ground signal and prevents the air conditioning system from operating.



A/C: Fans and Compressor Controls (PGM-FI)

Circuit Schematic







(cont'd)

A/C: Fans and Compressor Controls (PGM-FI)

Circuit Schematic (cont'd)





Component Location Index

(Refer to Section 201 for photographs.)

A/C Compressor Clutch	17	C213 (4-WHT)	
Lower left front of engine		Lower left front of engine compartment, near A/C compressor	
A/C Compressor Clutch Relay A	89	C236 (14-WHT).	16
Right front corner of engine compartment		Right rear corner of engine compartment	
A/C Compressor Clutch Relay B	89	C243 (14-WHT).	38
Right front corner of engine compartment		Right front of engine compartment, behind front bumper	
A/C Compressor Control Unit	90	C252 (20-BLK)	61
Behind right side of dash		On electronic control unit	
A/C Diodes	38	C257 (20-GRN).	58
Right front of car, behind bumper		Behind right side of dash	
Condenser Fan Motor	95	C284 (2-WHT)	
Left rear of radiator		Lower left front of engine compartment, near A/C compressor	
Condenser Fan Relay	96	C285 (2-GRN).	95
In under-hood relay box		Lower left front of engine compartment	
Coolant Temperature Switch A	47	C421 (20-WHT).	71
On radiator, below coolant fan		Behind left kick panel	
Coolant Temperature Switch B	97	C428 (14-YEL)	72
Top right front of engine		On rear of dash fuse box	
Cooling Fan Timer Unit	85	C430 (10-YEL)	72
Below right side of dash, on kick panel		On rear of dash fuse box	
Dash Fuse Box	70	C445 (22-WHT).	112
Behind left side of dash		Under right side of dash	
Evaporator Sensor	65	C446 (23-GRN).	73
Behind dash, at evaporator		Under right side of dash	
PGM-FI Electronic Control Unit	91	C449 (18-WHT).	112
Underside of passenger's footrest		Under right side of dash	
Radiator Fan Motor	9	G101	8
Right rear of radiator		On top right side of engine	
Radiator Fan Relay	96	G201	12
In under-hood relay box		Right side of engine compartment	
Under-Hood Relay Box	102	G202	12
Right side of engine compartment		Right side of engine compartment	
C201 (2-WHT)	9	G401	74
Lower right front of engine compartment		Behind top center of dash	
C212 (2-GRN).	95		
Lower left front of engine compartment			

A/C: Fans and Compressor Controls (PGM-FI)

How The Circuit Works

Fans

The cooling fan timer unit operates the radiator and condenser fans according to the temperature of the engine coolant. Both fans are turned on when the coolant temperature rises above 194°F (90°C) and are turned off when the coolant temperature falls below 181°F (83°C). If the engine coolant temperature is above 226°F (108°C) when the ignition is turned off, the cooling fan timer will run the condenser fan for a maximum of 15 minutes or until the engine coolant temperature drops to 214°F (101°C). The cooling fan timer unit controls the fans by operating the radiator and condenser fan relays.


Closure of coolant temperature switch A initiates the operation of both fans at 194°F (90°C). Closure of coolant temperature switch B affects only the condenser fan and is used for initiating operation of the condenser fan at ignition turn-off.

Compressor Control

When the A/C switch and the blower switch are turned on, a ground is applied from the heater control panel through the evaporator sensor, the A/C pressure switch and the A/C diodes to the cooling fan timer unit and the PGM-FI electronic control unit. The cooling fan timer unit energizes both fans. The electronic control unit increases the engine idle speed and signals the A/C compressor control unit to operate compressor clutch relays A and B, which will engage the A/C compressor clutch.


When the evaporator temperature drops below 37°F (3°C), the evaporator sensor opens its contacts, removing the ground from the cooling fan timer and electronic control unit. Both cooling fans and the A/C compressor clutch are de-energized until the evaporator temperature rises to a point where additional cooling is required. The evaporator sensor then closes its contacts and the cycle is repeated.



If refrigerant pressure becomes too high due to blockage or too low due to leakage, the A/C pressure switch contacts open, which interrupts the ground signal and prevents the air conditioning system from operating.




A/C: Air Delivery

Circuit Schematic







A/C: Air Delivery

Component Location Index


(Refer to Section 201 for photographs.)


Dash Fuse Box	70
Behind left side of dash	
Heater Function Control Motor	59
Behind center of dash	
Heater Recirculation Control Motor	57
Behind right side of dash	
C415 (8-WHT)	59
Behind center of dash	
C430 (10-YEL)	72
On rear of dash fuse box	
C441 (4-WHT)	93
Under right side of dash	
G401	74
Behind top center of dash	

How The Circuit Works

The heating and ventilating system has five modes: Vent, Hi-lo, Heat, H/Def, and Def. You select each mode by a pushbutton switch on the heater control panel. The system will recirculate the air in the car or draw air from the outside, depending on the position of the recirculation control pushbuttons.


See Section 21 of the Service Manual for circuit description and troubleshooting procedures.







Integrated Control Unit

Circuit Schematic







(cont'd)

Integrated Control Unit

Circuit Schematic (cont'd)





Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Integrated Control Unit	64
Behind center of dash	
C428 (14-YEL)	72
On rear of dash fuse box	
C430 (10-YEL)	72
On rear of dash fuse box	
C431 (4-YEL)	72
On rear of dash fuse box	
C433 (12-BLU)	64
Behind center of dash, on integrated control unit	
C434 (4-WHT)	64
Behind center of dash, on integrated control unit	
C435 (16-BLU)	64
Behind center of dash, on integrated control unit	
G401	74
Behind top center of dash	

How The Circuit Works

The integrated control unit combines several circuits sharing common circuit functions.

Entry Light Timer Circuit

For information on how the circuit works, see the Entry Light Timer System circuit.

Oil Pressure Warning/Flasher Circuit

For information on how the circuit works, see the Oil Pressure Warning System circuit.

Lights-on Warning and Key-on Beeper Circuit

For information on how the circuit works, see the Seat Belt, Lights-on and Ignition Key-on Warning circuit.

Side Marker Relay Circuit

For information on how the circuit works, see the Front Side Marker Lights circuit.

Intermittent Wiper Relay Circuit


For information on how the circuit works, see the Wiper/Washer circuit.


Automatic Seat Belt

For information on how the circuit works, see the Automatic Seat Belt circuit.

Brake Warning System

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Brake Fluid Level Switch	1
Left rear of engine compartment, in brake fluid reservoir	
Dash Fuse Box	70
Behind left side of dash	
Parking Brake Switch	55
At base of parking brake lever	
C313 (1-BLK)	1
Left rear of engine compartment	
C314 (1-BLK)	1
Left rear of engine compartment	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C421 (20-WHT)	71
Behind left kick panel	
C426 (7-YEL)	72
On rear of dash fuse box	
C712 (14-YEL)	107
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
G301	114
Left front corner of engine compartment	
G471	20
Behind right side of rear seat	

How The Circuit Works

The brake warning indicator light goes on to alert the driver that the parking brake is applied, or that the brake fluid level is low. It also lights as a bulb test when cranking the engine.

Parking Brake

With the ignition switch in RUN or START, voltage is applied through fuse 13 to the brake warning indicator light. When you apply the parking brake, the switch closes and provides a ground for the light: The brake warning indicator light goes on to remind the driver that the parking brake is applied.

Brake Fluid Level


With the ignition switch in RUN or START, voltage is applied through fuse 13 to the brake warning indicator light. If the brake fluid level is low, the brake fluid level switch closes and ground is provided to the circuit: The brake warning indicator light operates to warn the driver of low brake fluid level in the brake master cylinder. (Note: Check brake pad wear before adding fluid.)


Bulb Check

With the ignition switch in START, voltage is applied through fuse 1 to the bulb check unit of the warning display. The bulb check unit closes the circuit, allowing current to flow through the brake warning indicator light and bulb check unit to ground: The brake warning indicator light goes on to test the brake warning indicator light bulb.

Oil Pressure Warning System

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Engine Oil Pressure Switch	
Rear of engine, above oil filter	
Integrated Control Unit	64
Behind center of dash	
C238 (8-WHT)	56
Right side of engine compartment	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C428 (14-YEL)	72
On rear of dash fuse box	
C434 (4-WHT)	64
Behind center of dash, on integrated control unit	
C435 (16-BLU)	64
Behind center of dash, on integrated control unit	
C445 (22-WHT)	112
Under right side of dash	
C712 (14-YEL)	107
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
G401	74
Behind top center of dash	

How The Circuit Works

The oil pressure warning indicator light works in two ways. It flashes continuously following a momentary loss of oil pressure, or it goes on and stays on with a complete loss of oil pressure.


When the engine first starts, before oil pressure rises above 20 psi, voltage is applied to the oil pressure warning indicator light and the oil pressure switch to ground. This tests the bulb.



With the engine running, voltage is applied at the WHT/BLU wire of the integrated control unit. With normal oil pressure, the oil pressure switch is open and the oil pressure warning indicator light does not go on. If the oil pressure switch closes momentarily (more than 0.5 seconds) but then opens again, the YEL/RED wire at the integrated control unit will sense ground through the switch. The integrated control unit will then provide and remove ground for the oil pressure warning indicator light through the YEL/RED wire. The light will flash on and off until you turn the ignition switch off. The flashing feature will not work until 30 seconds after the initial voltage is applied to the WHT/BLU wire of the oil flasher unit. This delay avoids unnecessary warning light operation.

If engine oil pressure falls below 20 psi and does not increase, the oil pressure switch will stay closed. The oil pressure warning indicator light will go on and stay on.

Lights-on and Key-on Warning

Circuit Schematic





Lights-on and Key-on Warning

Component Location Index

(Refer to Section 201 for photographs.)

Chime	94
Below left side of dash	
Dash Fuse Box	70
Behind left side of dash	
Ignition Key Switch	87
In ignition switch mechanism, behind steering column covers	
Integrated Control Unit	64
Behind center of dash	
Left Door Switch	116
Lower section of left "B" pillar	
C414 (4-BLU)	78
Under center of dash, near steering column	
C416 (22-WHT)	78
Under left side of dash, right of steering column	
C426 (7-YEL)	72
On rear of dash fuse box	
C428 (14-YEL)	72
On rear of dash fuse box	
C430 (10-YEL)	72
On rear of dash fuse box	
C434 (4-WHT)	64
Behind center of dash, on integrated control unit	
C435 (16-BLU)	64
Behind center of dash, on integrated control unit	
C702 (2-WHT)	94
Under left side of dash	
C906 (8-WHT)	80
On front of dash fuse box	
G401	74
Behind top center of dash	
G471	20
Behind right side of rear seat	


How The Circuit Works

Key-on Warning

When the ignition key switch is closed, a ground is provided at the BLU/WHT wire of the integrated control unit. When you open the driver's door, ground is also provided at the GRN/BLU wire of the integrated control unit: The buzzer sounds.


Lights-on Warning


Voltage is applied at all times to the headlight switch. When the headlight switch is in PARK or HEAD, voltage is applied to the RED/BLK wire of C435. When you open the driver's door, the integrated control unit senses ground at the GRN/BLU wire of C435. If voltage is at the RED/BLK wire and ground is at the GRN/BLU wire, the lights-on chime module sounds.



Low Fuel Warning System

Circuit Schematic






Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Fuel Gauge Sending Unit	
Below rear of car, top of fuel tank	
C416 (22-WHT)	78
Under left side of dash, right of steering column	
C712 (14-YEL)	107
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
G401	74
Behind top center of dash	


How The Circuit Works



The thermistor is mounted in the fuel tank unit. When the thermistor is cool, its resistance is very high. When the thermistor is warm, its resistance is lower. Fuel in the fuel tank transfers heat away from the thermistor fast enough to keep it cool. The thermistor's resistance stays high and the low fuel warning indicator light does not go on. When the fuel level drops below about 2.9 gallons, the thermistor is no longer immersed in fuel. Without the fuel to cool it, the thermistor's resistance is low. Current flows through the low fuel warning indicator light and the thermistor to ground: The low fuel warning indicator light goes on.



Indicators

Circuit Schematic





Indicators


Component Location Index


(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
C426 (7-YEL)	72
On rear of dash fuse box	
C709 (12-WHT)	81
On rear of gauge assembly	
C712 (14-YEL)	107
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
G471	20
Behind right side of rear seat	

How The Circuit Works


The indicator lights are controlled by different conditions set forth in their associated system. See the associated system for the indicator light circuit description.






Gauges

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Coolant Temperature Gauge Sender	8
Top right front of engine	
Dash Fuse Box	70
Behind left side of dash	
Fuel Gauge Sending Unit	
Below rear of car, top of fuel tank	
Ignition Coil	15
Right rear of engine compartment	
C227 (2-WHT)	15
On ignition coil	
C238 (8-WHT)	56
Right side of engine compartment	
C257 (20-GRN)	58
Behind right side of dash	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C426 (7-YEL)	72
On rear of dash fuse box	
C445 (22-WHT)	112
Under right side of dash	
C709 (12-WHT)	81
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
G401	74
Behind top center of dash	
G471	20
Behind right side of rear seat	

How The Circuit Works

The coolant temperature gauge and the fuel gauge are each operated by two intersecting coils wound around a permanent magnet rotor. When voltage from fuse 13 is applied to the coils, a magnetic field is generated. This causes the rotor to rotate and the gauge needle to move. The magnetic field is controlled by the sender. As the resistance in the sender varies, current through the gauge coils changes. The gauge needle moves according to the changing magnetic field.

The coolant temperature sender's resistance varies from approximately 142 ohms at low engine temperature to approximately 32 ohms at high engine temperature.


The fuel gauge sender's resistance varies from approximately 5 ohms at full to approximately 105 ohms at empty. Damper oil surrounding the fuel gauge allows the fuel level to be shown when the ignition is off.


With the engine running, the tachometer senses ignition pulses from the distributor through the igniter unit. The solid-state tachometer displays these pulses as engine speed. With 200 pulses per minute from the igniter unit, the tachometer displays 100 rpm.

Gauges


Troubleshooting

Symptom	Troubleshoot
Fuel gauge and coolant temperature gauge do not operate.	A
Fuel gauge does not operate correctly.	B
Coolant temperature gauge does not operate correctly.	C
Inaccurate fuel gauge reading at all times — fuel gauge sender test.	D
Inaccurate coolant temperature gauge — coolant temperature gauge sender test.	E





Troubleshooting A





(cont'd)

Gauges


Troubleshooting (cont'd)

Troubleshooting B





(Continued from facing page)




(cont'd)

Gauges


Troubleshooting (cont'd)

Troubleshooting C





(Continued on page 81-10)

(Continued on facing page)



(Continued from facing page)



(cont'd)

Gauges

Troubleshooting (cont'd)

Troubleshooting D

Fuel gauge sender test.

(Continued from page 81-4)



WARNING: Do not smoke while working on fuel system. Keep an open flame away from work area.

Turn ignition off.

Disconnect fuel gauge sending unit connector C484.

Remove the fuel gauge sender.

Move the float to position "A" as shown.

Measure the resistance between terminals A and B of the fuel gauge sender.

Is the resistance between 105 and 110 ohms?

NO

Replace the fuel gauge sending unit.

YES

Move the float to position "B" as shown.

Measure the resistance between terminals A and B of the fuel gauge sender.


Is the resistance between 25.5 and 39.5 ohms?

NO

Replace the fuel gauge sending unit.


YES

Move the float to position "C" as shown.



FUEL GAUGE SENDING UNIT

(Continued on facing page)



(Continued from facing page)


Measure the resistance between terminals A and B of the fuel gauge sender.

Is the resistance between 2 and 5 ohms?

NO Replace the fuel gauge sending unit.

YES

Check the YEL/WHT and BLK wires to the fuel gauge sending unit connector for high resistance. If wires are good, replace fuel gauge.





(cont'd)

Gauges

Troubleshooting (cont'd)


Troubleshooting E






Safety Indicator

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Left Door Switch	116
Lower section of left "B" pillar	
Right Door Switch.	116
Lower section of right "B" pillar	
C417 (24-WHT).	78
Under left side of dash, right of steering column	
C426 (7-YEL)	72
On rear of dash fuse box	
C713 (16-YEL)	81
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
C724 (14-WHT).	80
Behind LH side of dash, on front of dash fuse box	
G471	20
Behind right side of rear seat	

How The Circuit Works

With the ignition switch in RUN or START, voltage is applied to the safety indicator. The safety indicator lights the appropriate display according to the corresponding input signal. The brightness of the safety indicator display is controlled by the dash lights dimmer when the headlight switch is in PARK or HEAD.

Trunk Light

For information on how the circuit works, see the Trunk Light circuit.

Brake Light Bulb Failure Warning

For information on how the circuit works, see the Brake Lights circuit.

Dome Light


For information on how the circuit works, see the Dome Light circuit.


Retractable Headlights

For information on how the circuit works, see the Retractable Headlights circuit.

Shift Lever Position Indicator

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Shift Position Console Switch	60
In console, below shift lever	
C418 (10-BLU)	78
Under left side of dash, right of steering column	
C426 (7-YEL)	72
On rear of dash fuse box	
C462 (10-WHT)	60
On center of floor, near gear selector	
C711 (10-WHT)	81
On rear of gauge assembly	
C713 (16-YEL)	81
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
G401	74
Behind top center of dash	
G471	20
Behind right side of rear seat	

How The Circuit Works


With the ignition switch in RUN or START, voltage is applied to the shift lever position indicator. The gear selector switch provides a ground for each position. As an input is grounded, its indicator lights. If R is selected, for example, a ground will be applied to the input of the shift position indicator, and the R indicator will light.


With the headlight switch in PARK or HEAD, voltage is applied to the RED/BLK wire terminal. This changes indicator panel illumination from fixed to controlled by the dash lights dimmer input on the RED wire.

The S₄ and S₃ indicators are controlled by the automatic transmission control unit. See Automatic Transmission and Section 14 of the Service Manual for circuit description and troubleshooting procedures.

Wiper/Washer

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Integrated Control Unit	64
Behind center of dash	
Windshield Washer Motor	108
Behind left side of bumper, below washer fluid reservoir	
Windshield Wiper Motor	2
Left rear corner of engine compartment	
C315 (5-WHT)	2
Left rear of engine compartment	
C421 (20-WHT)	71
Behind left kick panel	
C426 (7-YEL)	72
On rear of dash fuse box	
C428 (14-YEL)	72
On rear of dash fuse box	
C430 (10-YEL)	72
On rear of dash fuse box	
C431 (4-YEL)	72
On rear of dash fuse box	
C434 (4-WHT)	64
Behind center of dash, on integrated control unit	
C435 (16-BLU)	64
Behind center of dash, on integrated control unit	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
C907 (10-WHT)	80
On front of dash fuse box	
G301	114
Left front corner of engine compartment	
G471	20
Behind right side of rear seat	

How The Circuit Works

Low Speed

With the ignition switch in RUN or START, battery voltage is applied to the windshield wiper motor. When the wiper switch is moved to LO, the low speed winding of the motor is grounded through the low contact of the combination switch. The wipers run at low speed. A cam switch attached to the wiper motor signals the integrated control unit as to the position of the wipers.

Park/Off

When the wiper switch is turned off, the integrated control unit provides a ground for the windshield wiper motor. When the cam switch on the motor signals the integrated control unit that the wipers are in the park position, the control unit removes the grounds for the motor. The wipers stop in the parked position.

High Speed

When the wiper switch is in HI, the high speed winding of the windshield wiper motor is grounded through the high contact of the combination switch: The wipers run at high speed.

Intermittent

When the wiper switch is moved to INT, battery voltage is applied through the GRN wire to the integrated control unit. The integrated control unit's intermittent wiper relay circuit provides ground to the low speed windings of the wiper motor: The wipers make a single sweep approximately once every five seconds.

Mist


When the wiper switch is moved to MIST and released, the high speed winding of the windshield wiper motor is grounded through the mist contact in the combination switch. The wipers make one sweep at high speed and return to the park position.


Washer

When the washer switch is depressed, battery voltage is applied to the windshield washer motor. The motor pumps fluid on the windshield until the switch is released.

Headlights

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Dimmer Relay	11
In under-hood relay box	
Lighting Relay	11
In under-hood relay box	
Retractable Headlight Control Unit	62
On left kick panel	
Under-Hood Relay Box	102
Right side of engine compartment	
C411 (14-GRN)	70
Behind left side of dash	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C422 (4-WHT)	71
Behind left kick panel	
C426 (7-YEL)	72
On rear of dash fuse box	
C444 (4-WHT)	112
Under right side of dash	
C445 (22-WHT)	112
Under right side of dash	
C446 (23-GRN)	73
Under right side of dash	
C448 (7-WHT)	73
Under right side of dash	
C709 (12-WHT)	81
On rear of gauge assembly	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
G201	12
Right side of engine compartment	
G401	74
Behind top center of dash	
G471	20
Behind right side of rear seat	

How The Circuit Works

Low Beam Operation

Voltage is applied at all times to the lighting relay. With the headlight switch in HEAD, ground is applied to the lighting relay coil, and the contacts close. Voltage is applied through the fuses to the headlights. The low filaments of the dual beam headlights are grounded through the dimmer relay contacts: The low beams go on.

High Beam Operation

Voltage is applied to the headlights the same way as it is in low beam operation. Voltage is applied through the lighting relay contacts to the dimmer relay coil. With the dimming switch in HI, ground is applied to the dimmer relay coil and the relay energizes. The high filaments of the dual beam headlights and the high beam headlights are grounded through the dimmer relay contacts: The high beams go on.

Voltage is applied through the low filaments of the headlights to the high beam indicator light: The indicator light goes on.


Flash Operation


The flash feature works with the headlight switch off, or in PARK, or HEAD (low beams). With the passing switch in FLASH, ground is applied to the lighting relay coil. The lighting relay energizes and applies voltage to the headlights and the dimmer relay coil. The dimmer relay coil is grounded through the passing switch. The dimmer relay energizes and applies ground to the high filaments of the headlights: The high beams go on.

The flash function has no effect if high beams are already on.

Fog Lights: PGM-FI

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)


Dash Fuse Box	70
Behind left side of dash	
Dash Relay Holder	98
Behind left side of dash	
Fog Light Relay	63
Behind left side of dash, on relay holder	
Under-Hood Relay Box	102
Right side of engine compartment	
C206 (1-BLK)	52
Behind right side of front bumper, on right horn	
C208 (2-RED)	66
Behind right side of front bumper	
C303 (2-RED)	67
Behind left side of front bumper	
C411 (14-GRN)	70
Behind left side of dash	
C416 (22-WHT)	78
Under left side of dash, right of steering column	
C421 (20-WHT)	71
Behind left kick panel	
C430 (10-YEL)	72
On rear of dash fuse box	
C445 (22-WHT)	112
Under right side of dash	
G201	12
Right side of engine compartment	
G301	114
Left front corner of engine compartment	
G401	74
Behind top center of dash	


How The Circuit Works

The fog lights are controlled indirectly through the fog light relay by the fog light switch, headlight switch and dimming switch. With the headlight switch in the HEAD position battery voltage is applied to the fog light relay coil. With the fog light switch in the ON position, the dimming switch in LO, and the headlight switch ON a current path is created to the fog light relay coil. The fog light relay is energized and voltage from fuse 9 is applied to the fog lights. If the dimming switch is in the HI position, the headlight switch is not in the HEAD position or the fog light switch is turned off, the relay coil is de-energized and the fog lights are turned off.

Retractable Headlights

Circuit Schematic






Retractable Headlights

Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70	C421 (20-WHT).	71
Behind left side of dash		Behind left kick panel	
Left Headlight Retractor Motor	4	C430 (10-YEL)	72
Left front corner of engine compartment		On rear of dash fuse box	
Left Headlight Retractor Relay	4	C445 (22-WHT).	112
Left front corner of engine compartment		Under right side of dash	
Retractable Headlight Control Unit	62	C446 (23-GRN).	73
On left kick panel		Under right side of dash	
Right Headlight Retractor Motor	10	C713 (16-YEL)	81
Right front corner of engine compartment		On rear of gauge assembly	
Right Headlight Retractor Relay	10	C724 (14-WHT).	80
Right front corner of engine compartment		Behind LH side of dash, on front of dash fuse box	
Under-Hood Relay Box	102	C906 (8-WHT)	80
Right side of engine compartment		On front of dash fuse box	
C205 (6-WHT)	10	G201	12
Right front corner of engine compartment		Right side of engine compartment	
C309 (6-WHT)	4	G202	12
Left front corner of engine compartment		Right side of engine compartment	
C411 (14-GRN).	70	G301	114
Behind left side of dash		Left front corner of engine compartment	
C416 (22-WHT).	78	G302	114
Under left side of dash, right of steering column		Left front corner of engine compartment	
C417 (24-WHT).	78	G401	74
Under left side of dash, right of steering column		Behind top center of dash	



How The Circuit Works

The headlights can be raised or retracted with the headlight motor switch on the instrument panel or with the light switch on the turn signal lever.

Headlight Motor Switch Operation

With the headlights retracted, the headlight switch in off, and the headlight motor switch pressed in (RAISE), current flows through the headlight motor switch, the LH headlight retractor motor up contact, and the LH headlight retractor relay coil to ground. The relay operates, and current flows through the relay contacts and LH headlight retractor motor to ground. The motor operates to raise the headlight. With the headlight fully raised, the LH headlight retractor motor up contact opens and current to the LH headlight retractor relay is stopped. The relay moves to the position shown in the schematic and current to the motor is cut off: The motor stops. Similar current flow occurs at the same time for the RH retractor relay and motor.

When the headlight retractor relay contacts return to the de-energized state, ground is connected to both sides of the retractor motor. This acts as a dynamic brake to stop the motor quickly.

With the headlights raised, the headlight switch off, and the headlight motor switch released (RETRACT), current flows through the headlight motor switch, the retractable headlight control unit down contacts, the LH headlight retractor motor down contact, and the LH headlight retractor relay coil to ground. The motor operates to retract the headlights. With the headlights fully retracted, the LH headlight retractor motor down contact opens and current to the LH headlight retractor relay is stopped. The relay moves to the position shown in the schematic and current to the motor is cut off: The motor stops.

Similar current flow occurs at the same time for the RH headlight retractor relay and motor.

Headlight Switch Operation

With the headlight motor switch in RETRACT and the headlight switch moved to HEAD current flows through the retractable headlight control unit coil to ground. The control unit contacts move to up and current flows through the headlight motor switch RETRACT contacts and control unit up contacts to the LH retractor motor. From this point, current flow

to raise the headlights is the same as described in Headlight Motor Switch Operation above. With the headlight motor switch in RETRACT and the headlight switch moved from HEAD to PARK, voltage to the retractable headlight control unit terminal "E" is cut off. The controller applies voltage to the coil to keep the contacts closed in the up position.

With the headlight motor switch in RETRACT and the headlight switch moved to off voltage is applied to terminal "B" of the retractable headlight control unit. Voltage is removed from the control unit coil, and the control unit contacts move to "DN". Current flows through the headlight motor switch retract contacts and control unit down contacts to the LH retractor motor. From this point, current flow to retract headlights is the same as described in Headlight Motor Switch Operation, above.


Safety Indicator Operation


Voltage is applied to terminals H and I of the retractable headlight control unit whenever the headlight retractor relays operate to activate the headlight retractor motors. The relays operate only for the short time it takes the headlights to rise or retract. With the headlights operating normally, the time that this voltage is applied to the timer is fixed and equal between terminals H and I. If the voltage is applied for too long, not long enough, or unequally, the timer sends a signal to the safety indicator. The safety indicator lights the headlight motor warning light symbol on the safety indicator panel to indicate a problem with the headlight retractors.

Retractable Headlights


Troubleshooting

Symptom	Troubleshooting
Both headlights are stuck in raised position. Neither switch will make them retract.	A
Both retractor motors do not work from the headlight switch but do work from the headlight motor switch.	B
Both retractor motors do not work from the headlight motor switch but do work from the headlight switch.	C
Headlights retract when headlight switch is moved from HEAD to PARK.	D
A single motor is inoperative.	E







Troubleshooting A




Retractable Headlights

Troubleshooting (cont'd)





Troubleshooting B



Retractable Headlights

Troubleshooting (cont'd)

Troubleshooting C

Both retractor motors do not work from the headlight motor switch but do work from the headlight switch.

Disconnect C704.

Jumper the WHT/RED and WHT/BLK wires of C704 together.

Do the headlights rise?

YES

Replace the headlight motor switch.


NO

Repair the open in the WHT/BLK wire between C704 and S453.


Troubleshooting D

Headlights retract when headlight switch is moved from HEAD to PARK.

If all other functions work properly, replace the control unit. If any other function does not work refer to the related tree.



Troubleshooting





(Continued on next page)

Retractable Headlights

Troubleshooting


(Continued from previous page)







Front Side Marker Lights

Circuit Schematic






Front Side Marker Lights

Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70	C434 (4-WHT)	64
Behind left side of dash		Behind center of dash, on integrated control unit	
Dash Relay Holder	98	C435 (16-BLU)	64
Behind left side of dash		Behind center of dash, on integrated control unit	
Integrated Control Unit	64	C445 (22-WHT)	112
Behind center of dash		Under right side of dash	
Turn Signal/Hazard Relay	63	C446 (23-GRN)	73
Behind left side of dash, on relay holder		Under right side of dash	
Under-Hood Relay Box	102	C513 (2-WHT)	82
Right side of engine compartment		Upper right side of trunk	
C209 (3-GRN)	69	C724 (14-WHT)	80
Behind right side of front bumper		Behind LH side of dash, on front of dash fuse box	
C304 (3-GRN)	69	C906 (8-WHT)	80
Behind left side of front bumper		On front of dash fuse box	
C417 (24-WHT)	78	G201	12
Under left side of dash, right of steering column		Right side of engine compartment	
C421 (20-WHT)	71	G302	114
Behind left kick panel		Left front corner of engine compartment	
C426 (7-YEL)	72	G401	74
On rear of dash fuse box		Behind top center of dash	
C430 (10-YEL)	72		
On rear of dash fuse box			



How The Circuit Works

With the headlight switch in PARK or HEAD, voltage is applied to the integrated control unit: The front side marker lights go on.

Turn Operation

With the ignition switch in RUN or START and the turn signal switch in LEFT, voltage is applied to the coil and flasher of the turn signal/hazard relay. The solid-state flasher provides a ground for the relay coil. The coil controls the relay contacts. As the contacts open and close, the integrated control unit receives an on-off voltage which causes the left front side marker light to flash.

The right front side marker light operates the same way.

With the headlight switch in OFF, the front side marker lights flash simultaneously with the front and rear turn signal.


With the headlight switch in HEAD or PARK, the front side marker lights and the turn signal lights flash alternately.


Hazard Operation

With the hazard switch ON, voltage is always applied to the turn signal/hazard relay. Hazard operation is similar to turn operation, except both the right and left front side marker lights flash simultaneously.

Parking Lights

Circuit Schematic






Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
C209 (3-GRN).	69
Behind right side of front bumper	
C304 (3-GRN).	69
Behind left side of front bumper	
C421 (20-WHT).	71
Behind left kick panel	
C426 (7-YEL)	72
On rear of dash fuse box	
C445 (22-WHT).	112
Under right side of dash	
C724 (14-WHT).	80
Behind LH side of dash, on front of dash fuse box	
C906 (8-WHT)	80
On front of dash fuse box	
G201	12
Right side of engine compartment	
G302	114
Left front corner of engine compartment	


How The Circuit Works



Voltage is applied through fuse 15 to the headlight switch at all times. With the headlight switch in PARK or HEAD, voltage is applied to the parking lights: The parking lights go on.



Turn Signal and Hazard Lights

Circuit Schematic






Turn Signal and Hazard Lights

Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70	C486 (13-WHT).	26
Behind left side of dash		Upper right side of trunk	
Dash Relay Holder	98	C502 (8-WHT)	23
Behind left side of dash		In right rear of trunk	
Turn Signal/Hazard Relay	63	C508 (8-WHT)	25
Behind left side of dash, on relay holder		In left rear of trunk	
Under-Hood Relay Box	102	C709 (12-WHT).	81
Right side of engine compartment		On rear of gauge assembly	
C210 (2-WHT).	66	C724 (14-WHT).	80
Behind right side of front bumper		Behind LH side of dash, on front of dash fuse box	
C302 (2-WHT)	67	C906 (8-WHT)	80
Behind left side of front bumper		On front of dash fuse box	
C417 (24-WHT).	78	G201	12
Under left side of dash, right of steering column		Right side of engine compartment	
C421 (20-WHT).	71	G301	114
Behind left kick panel		Left front corner of engine compartment	
C426 (7-YEL)	72	G401	74
On rear of dash fuse box		Behind top center of dash	
C430 (10-YEL)	72	G471	20
On rear of dash fuse box		Behind right side of rear seat	
C445 (22-WHT).	112	G501	26
Under right side of dash		Right side of trunk	
C448 (7-WHT)	73		
Under right side of dash			



How The Circuit Works


Turn Signal Operation

Voltage is applied through fuse 31 to the turn signal/hazard relay contacts and flasher at all times. With the ignition switch in RUN or START and the turn signal switch in LEFT, voltage is applied to the left control coil of the turn signal/hazard relay. The solid-state flasher provides a ground for the relay coil. The coil controls the relay contacts. As the contacts open and close, the left turn signal lights and indicator light flash.

Right turn operation is similar to left turn operation. With the turn signal switch in the RIGHT position, the right turn signal lights and indicator light will both flash.


Hazard Flasher Operation


With the hazard switch ON, voltage is always applied to the turn signal/hazard relay coils, flasher, and contacts. The solid-state flasher provides a ground for the relay coils. The coils control the relay contacts. As the contacts open and close, all the turn signal lights and both indicator lights flash.



Tail, Rear Side Marker and License Plate Lights

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)


Dash Fuse Box	70
Behind left side of dash	
C426 (7-YEL)	72
On rear of dash fuse box	
C486 (13-WHT)	26
Upper right side of trunk	
C502 (8-WHT)	23
In right rear of trunk	
C504 (4-WHT)	19
Behind center of rear bumper	
C508 (8-WHT)	25
In left rear of trunk	
C906 (8-WHT)	80
On front of dash fuse box	
G501	26
Right side of trunk	


How The Circuit Works

Voltage is applied through fuse 15 to the headlight switch at all times. With the headlight switch in PARK or HEAD, voltage is applied to all the lights in this circuit: The tail, rear side marker, and license plate lights go on.



Brake Lights Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Brake Light Switch	86
Top of brake pedal support	
Dash Fuse Box	70
Behind left side of dash	
Left Brake Light Sensor	25
At left brake lights	
Right Brake Light Sensor	23
At right brake lights	
Under-Hood Relay Box	102
Right side of engine compartment	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C444 (4-WHT)	112
Under right side of dash	
C477 (2-WHT)	22
Above center of trunk	
C486 (13-WHT)	26
Upper right side of trunk	
C502 (8-WHT)	23
In right rear of trunk	
C508 (8-WHT)	25
In left rear of trunk	
C510 (2-WHT)	106
Underside of trunk lid	
C713 (16-YEL)	81
On rear of gauge assembly	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
G401	74
Behind top center of dash	
G501	26
Right side of trunk	

How The Circuit Works

With the brake switch closed, current flows through the brake switch, the brake light sensors' coils and the brake light filaments to ground: The brake lights go on. The brake light sensors' coils offer very little resistance to the brake light current.

Safety Indicator Input


If the safety indicator senses a burned out brake light filament, it lights up the "Brake Lamp" symbol on the safety indicator panel. The safety indicator senses ground through the brake light sensors and brake light filaments. With the brake switch open (brake lights off), the safety indicator senses ground through any of the five brake light sensors' coils and brake light filaments. The safety indicator does not light up the "Brake Lamp" symbol.


When the brake switch is closed (brake lights on), current through the brake light sensors' coils and brake lights to ground closes the brake light sensors' contacts. The safety indicator is then grounded through the brake light sensors' contacts. If all five brake light filaments are good, the safety indicator senses ground through the five sensor contacts. The safety indicator does not light up the "Brake Lamp" symbol.

If any one of the five brake light filaments is burned out, the brake light sensor coil for that filament does not receive ground, so its contacts remain open. With the contacts open, the safety indicator does not sense ground, so the indicator lights up the "Brake Lamp" symbol on the safety indicator panel. The symbol remains on until the ignition switch is turned off.

Back Up Lights

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)


Back Up Lights Switch	51
Top right side of transmission	
Dash Fuse Box	70
Behind left side of dash	
Shift Position Console Switch	60
In console, below shift lever	
C111 (1-BLK)	51
Above transmission	
C112 (1-BLK)	51
Above transmission	
C161 (1-BLK)	110
Right side of engine	
C162 (1-BLK)	110
Right side of engine	
C238 (8-WHT)	56
Right side of engine compartment	
C446 (23-GRN)	73
Under right side of dash	
C462 (10-WHT)	60
On center of floor, near gear selector	
C486 (13-WHT)	26
Upper right side of trunk	
G501	26
Right side of trunk	


How The Circuit Works

With the ignition switch in RUN or START, voltage is applied through fuse 13 to the shift position console switch (with automatic transmission), or to the back up lights switch (with manual transmission). When you shift the gear selector lever to reverse, the shift position console switch or the back up lights switch closes and voltage is applied to the back up lights: The back up lights go on.

Dome and Trunk Lights

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)


Dash Fuse Box	70
Behind left side of dash	
Trunk Switch	21
In rear of trunk	
C416 (22-WHT)	78
Under left side of dash, right of steering column	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C446 (23-GRN)	73
Under right side of dash	
C485 (8-WHT)	20
In right quarter panel	
C486 (13-WHT)	26
Upper right side of trunk	
C713 (16-YEL)	81
On rear of gauge assembly	

How The Circuit Works

Voltage is applied at all times through fuse 8 to the trunk and dome lights.


When you open the trunk lid, the trunk switch closes providing a path to ground for the trunk light circuit: The light goes on. The safety indicator senses that the trunk switch is closed and lights the trunk-open symbol on the indicator panel.


When the dome light switch is in the DOOR position and you open a door, a ground path is provided by the safety indicator through the closed light switch: The dome light goes on. With the door closed, you can turn on the dome light by turning the light switch to ON.



Cigarette Lighter

Circuit Schematic






Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
C430 (10-YEL)	72
On rear of dash fuse box	
C438 (4-WHT)	79
Behind center of dash	
G401	74
Behind top center of dash	


How The Circuit Works


Voltage is applied at all times through fuse 8 to the cigarette lighter. When you depress the lighter, the lighter element completes the circuit to ground. When the element becomes sufficiently heated, it is spring-released and the circuit opens.



Entry Light Timer System: PGM-FI

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Driver's Door Outer Handle Switch	31
In driver's door	
Ignition Key Switch	87
In ignition switch mechanism, behind steering column covers	
Integrated Control Unit	64
Behind center of dash	
Left Door Switch	116
Lower section of left "B" pillar	
C414 (4-BLU)	78
Under center of dash, near steering column	
C423 (18-WHT)	111
Behind right kick panel	
C430 (10-YEL)	72
On rear of dash fuse box	
C433 (12-BLU)	64
Behind center of dash, on integrated control unit	
C434 (4-WHT)	64
Behind center of dash, on integrated control unit	
C435 (16-BLU)	64
Behind center of dash, on integrated control unit	
C629 (4-WHT)	113
In rear half of driver's door	
G401	74
Behind top center of dash	
G471	20
Behind right side of rear seat	

How The Circuit Works


Voltage is applied at all times through fuse 8 to the ignition key switch light, the footwell light, and the door key light.



When you lift the driver's door handle, the driver's door outer handle switch input to the integrated control unit is grounded. The integrated control unit provides a path to ground for the ignition key light, the footwell light, and the door key light: The lights go on. When you open the driver's door, the left door switch closes and the lights stay on.

When you close the driver's door, the left door switch opens. The integrated control unit continues to provide ground for the light circuits for approximately eight seconds.

Dash and Console Lights

Circuit Schematic








(cont'd)

Dash and Console Lights

Circuit Schematic (cont'd)





Dash and Console Lights

Component Location Index


(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Integrated Control Unit	64
Behind center of dash	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C426 (7-YEL)	72
On rear of dash fuse box	
C434 (4-WHT)	64
Behind center of dash, on integrated control unit	
C435 (16-BLU)	64
Behind center of dash, on integrated control unit	
C438 (4-WHT)	79
Behind center of dash	
C440 (16-WHT)	79
On rear of stereo radio cassette player	
C464 (2-WHT)	60
On center of floor, near gear selector	
C701 (4-WHT)	94
Under left side of dash	
C709 (12-WHT)	81
On rear of gauge assembly	
C711 (10-WHT)	81
On rear of gauge assembly	
C712 (14-YEL)	107
On rear of gauge assembly	
C713 (16-YEL)	81
On rear of gauge assembly	
C716 (2-GRN)	77
Behind right center of dash	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
C904 (9-WHT)	
Behind LH side of dash, on front of dash fuse box	
C906 (8-WHT)	80
On front of dash fuse box	
G401	74
Behind top center of dash	
G471	20
Behind right side of rear seat	
G701	75
Behind center dash, on center frame	

How The Circuit Works


Voltage is applied at all times through fuse 15 to the headlight switch. With the headlight switch in HEAD or PARK, voltage is applied to the dash and console lights: The lights come on. The glove box light comes on when the glove box door is opened.

The lights connected with the RED wire to the dashlight brightness control unit can be dimmed by using the dashlight brightness controller, a variable resistor.





Power Window: Driver's Door

Circuit Schematic



Right Front Door

- Circuit Schematic



Power Windows: PGM-FI

Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Dash Relay Holder	98
Behind left side of dash	
Driver's Power Window Motor	28
In front half of drivers door	
Passenger's Power Window Motor	32
In front half of passenger's door	
Power Window Control Unit	29
In front half of driver's door	
Power Window Relay	98
Behind left side of dash, on relay holder	
Under-Hood Relay Box	102
Right side of engine compartment	
C423 (18-WHT)	111
Behind right kick panel	
C427 (6-YEL)	72
On rear of dash fuse box	
C428 (14-YEL)	72
On rear of dash fuse box	
C431 (4-YEL)	72
On rear of dash fuse box	
C447 (3-WHT)	73
Under right side of dash	
C451 (14-WHT)	58
Behind right kick panel	
C624 (6-WHT)	29
In front half of driver's door	
C625 (10-WHT)	28
In front half of driver's door	
C675 (6-WHT)	32
In center of passenger's door	
C676 (2-WHT)	32
In center of passenger's door	
G401	74
Behind top center of dash	
G471	20
Behind right side of rear seat	


How The Circuit Works

System Description

The operation of the power windows is controlled by the master switch in the driver's power window switch. When the main switch is off, only the driver's door window can be opened or closed. With the master switch in ON, all windows can be opened or closed by the driver's power window master switch or each window by its respective switch. The driver's window switch also has an automatic down mode which is controlled at the driver's power window switch.

The power windows are driven by reversible motors. Each motor is protected by a built-in circuit breaker. If a window switch is held on too long (with the window obstructed, or after the window is fully up or down) the circuit breaker opens the circuit. The circuit breaker resets automatically as it cools.

When the ignition switch is in RUN or START, voltage is applied to the coil in the power window relay. The contacts of the power window relay close and voltage is applied to the driver's power window switch, the power window control unit, and the passenger's power window switch. When the ignition switch is turned from RUN or START to ACC or OFF and both front doors are closed, the integrated control unit will keep the power window relay energized for approximately ten minutes or until one of the doors is opened.



Driver's Window

With the ignition switch in RUN or START, voltage is applied to the coil of the power window relay. The contacts of the power window relay close and voltage is applied through fuse 6 to the driver's power window switch and the power window control unit. When you move the driver's power window switch to UP, voltage is applied to the power window control unit up input. Voltage is then applied through the power window control unit (motor up control) to the driver's power window motor. The motor's ground path is back through the power window control unit. The power window motor drives the window up. When you move the driver's power window switch to DOWN, voltage is applied to the power window motor in the opposite direction: The motor drives the window down.

Automatic Down (Driver's Window)

With the ignition switch in RUN or START, voltage is applied to the coil of the power window relay. The contacts of the power window relay close and voltage is applied to the driver's power window master switch and the power window control unit. When you push the driver's switch to the AUTO DOWN position, voltage is applied through the driver's power window switch to the power window control unit's down and auto down hold inputs. The voltage triggers the power window control unit and voltage is applied from the power input through the motor down control output to the power window motor. The power window control unit receives voltage pulses at the pulser input while the motor is operating. When the window is fully down, the motor stops and pulses are no longer generated by the pulser. This is sensed by the power window control unit at the pulser input and voltage is no longer applied to the power window motor.

Passenger's Window


With the ignition switch in RUN or START, voltage is applied to the coil of the power window relay. The contacts of the power window relay close and voltage is applied through fuse 5 to the passenger's power window switch and the driver's power window switch. If you close the master switch in the driver's power window switch, the passenger's window can be operated from the individual window switch or from the driver's power window switch.


When you move the passenger's power window switch to UP, voltage is applied to the passenger's power window motor. The motor is grounded through the contacts in the passenger's power window switch and the driver's power window switch. The window moves up as long as the switch is held in the UP position. If the passenger's power window switch is moved to DOWN, voltage is applied to the passenger's power window motor in the opposite direction. The window moves down as long as the switch is held in the DOWN position.

When the driver's passenger window switch is moved to UP, voltage is applied through the passenger's power window switch contacts to the passenger's power window motor. The motor is grounded through the contacts in the passenger's power window switch and the driver's power window switch. The window moves up as long as the switch is held in the UP position. If the driver's passenger window switch is moved to DOWN, voltage is applied to the passenger's power window motor in the opposite direction. The window moves down as long as the switch is held in the DOWN position.

Sunroof

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Dash Relay Holder	98
Behind left side of dash	
Sunroof Close Relay	63
Behind left side of dash, on relay holder	
Sunroof Motor	
Center rear of roof	
Sunroof Open Relay	63
Behind left side of dash, on relay holder	
C417 (24-WHT)	78
Under left side of dash, right of steering column	
C431 (4-YEL)	72
On rear of dash fuse box	
C485 (8-WHT)	20
In right quarter panel	
C907 (10-WHT)	80
On front of dash fuse box	
G401	74
Behind top center of dash	
G471	20
Behind right side of rear seat	

How The Circuit Works

System Description

The sunroof is driven by a reversible motor which opens and closes the sunroof. Voltage is applied at all times through fuse 14 to the normally open contacts in the sunroof close relay and sunroof open relay. With the ignition switch in RUN or START, voltage is applied through fuse 11, the sunroof close relay coil, and the sunroof open relay coil to the sunroof switch contacts.

Opening the Sunroof


When the sunroof switch is in the OPEN position, the sunroof open relay coil is grounded through the sunroof switch open contacts to G471. The coil energizes and the sunroof open relay contacts close. Voltage is applied to the sunroof motor. The sunroof motor is grounded through the sunroof close relay contacts to G401. The sunroof motor operates to open the sunroof. The sunroof motor operates until the sunroof switch is moved from the OPEN position.



Closing the Sunroof

When the sunroof switch is in the CLOSE position, the sunroof close relay coil is grounded through the sunroof switch close contacts to G471. The coil energizes and the sunroof close relay contacts close. Voltage is applied to the sunroof motor. The sunroof motor is grounded through the sunroof open relay contacts to G401. The sunroof motor operates to close the sunroof. The sunroof motor operates until the sunroof switch is moved from the CLOSE position.

Power Door Locks (4WS)

Circuit Schematic





Power Door Locks (4WS)

Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Driver's Door Lock Actuator	31
In driver's door	
Driver's Power Door Lock Switch	
In driver's door	
Left Door Latch Switch/Door Lock Actuator	
In rear half of driver's door	
Passenger's Door Lock Actuator	34
In front half of passenger's door	
Power Door Lock Control Unit	35
In passenger's door	
Right Door Key Switch	
In passenger's door	
Right Door Lock Actuator	
In passenger's door	
C423 (18-WHT)	111
Behind right kick panel	
C424 (4-WHT)	111
Behind right kick panel	
C425 (6-WHT)	111
Behind right kick panel	
C428 (14-YEL)	72
On rear of dash fuse box	
C451 (14-WHT)	58
Behind right kick panel	
C452 (4-WHT)	58
Behind right kick panel	
C626 (3-WHT)	28
In front half of driver's door	
C630 (6-WHT)	113
In rear half of driver's door	
C679 (3-WHT)	34
In rear of passenger's door	
C680 (4-WHT)	34
In rear of passenger's door	
G471	20
Behind right side of rear seat	


How The Circuit Works

Voltage is applied at all times through fuse 4 to the power door lock control unit.

When you use the key to turn the left door lock actuator or right door key switch to the LOCK position, a path to ground is supplied to one of the control unit's lock inputs. The power door lock control unit applies voltage to the door lock actuators: The doors lock.


When you use the key to turn the left door lock actuator or right door key switch to the UNLOCK position, a path to ground is supplied to the control unit's unlock input. Voltage is applied to the door lock actuators: The polarity of the voltage applied to the actuators is now reversed and the doors unlock.


Both doors can be electrically locked and unlocked from the driver's power door lock switch. Both doors can also be unlocked mechanically from the outside with a key.



Power Door Mirrors: PGM-FI

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)


Dash Fuse Box	70
Behind left side of dash	
C419 (8-WHT)	78
Under left side of dash, right of steering column	
C423 (18-WHT)	111
Behind right kick panel	
C426 (7-YEL)	72
On rear of dash fuse box	
C451 (14-WHT)	58
Behind right kick panel	
C623 (3-WHT)	29
In front half of driver's door	
C673 (3-WHT)	35
In front half of passenger's door	
C724 (14-WHT)	80
Behind LH side of dash, on front of dash fuse box	
G471	20
Behind right side of rear seat	

How The Circuit Works

The operation of the two outside mirrors is controlled by the power mirror control switch. Each mirror has two reversible motors: One motor moves the mirror up and down, the other motor moves the mirror left and right. The power mirror control switch directs voltage to the right and left outside mirrors.


With the ignition switch in RUN, voltage is applied through fuse 17 to the power door mirror switch. With the master selector switch in LEFT and up/down switch in UP, voltage is applied through the up contacts of the up/down switch to the left power mirror up/down motor. Ground is provided through the left contacts of the master selector switch and the up contacts of the up/down switch: The mirror goes up. In the DOWN position, voltage is applied to the opposite side of the mirror.


The left/right switch works similarly to the up/down switch. With the master selector switch in the RIGHT position, voltage is applied to the right power mirror motors which then operate in a similar way.



Automatic Seat Belt

Circuit Schematic







(cont'd)

Automatic Seat Belt

Circuit Schematic (cont'd)






Automatic Seat Belt



Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70	C451 (14-WHT)	58
Behind left side of dash		Behind right kick panel	
Driver's Seat Belt Retractors	30	C453 (6-WHT)	58
In rear half of driver's door		Behind right kick panel	
Driver's Seat Belt Switch		C474 (2-WHT)	
In driver's seat belt buckle		Under right front seat	
Front Passenger's Seat Belt Retractors	33	C485 (8-WHT)	20
In rear half of passenger's door		In right quarter panel	
Integrated Control Unit	64	C487 (2-WHT)	
Behind center of dash		Under driver's seat	
Left Door Latch Switch/Door Lock Actuator		C627 (4-WHT)	30
In rear half of driver's door		In rear half of driver's door	
Passenger's Seat Belt Switch		C628 (4-WHT)	30
In passenger's seat belt buckle		In rear half of driver's door	
Right Door Latch Switch/Door Lock Actuator		C630 (6-WHT)	113
In rear half of passenger's door		In rear half of driver's door	
Seat Belt Beeper/Reminder Assembly	117	C677 (4-WHT)	33
Center of windshield header		In rear half of passenger's door	
Speed Sensor Amplifier	107	C678 (4-WHT)	33
On rear of gauge assembly		In rear half of passenger's door	
Vehicle Speed Sensor	107	C680 (4-WHT)	34
In gauge assembly		In rear of passenger's door	
C416 (22-WHT)	78	C709 (12-WHT)	81
Under left side of dash, right of steering column		On rear of gauge assembly	
C421 (20-WHT)	71	C710 (7-YEL)	81
Behind left kick panel		On rear of gauge assembly	
C423 (18-WHT)	111	C712 (14-YEL)	107
Behind right kick panel		On rear of gauge assembly	
C425 (6-WHT)	111	C723 (4-WHT)	94
Behind right kick panel		Under left side of dash, on dash fuse box	
C426 (7-YEL)	72	C724 (14-WHT)	80
On rear of dash fuse box		Behind LH side of dash, on front of dash fuse box	
C428 (14-YEL)	72	G401	74
On rear of dash fuse box		Behind top center of dash	
C433 (12-BLU)	64	G471	20
Behind center of dash, on integrated control unit		Behind right side of rear seat	
C434 (4-WHT)	64	G701	75
Behind center of dash, on integrated control unit		Behind center dash, on center frame	
C435 (16-BLU)	64		
Behind center of dash, on integrated control unit			



How The Circuit Works

Battery voltage is applied to the integrated control unit through fuse 13 with the ignition switch in RUN or START.

When you open a door, the corresponding door latch switch closes. This provides a ground for the shoulder and lap solenoids. The solenoids energize, and disable the inertia switch in the seat belt retractor. This allows you to open and close the doors freely when the seat belt is buckled, without the door motion causing the seat belt retractors to lock up.


When you close a door the corresponding door latch switch opens, removing the ground for the shoulder and lap solenoids. The solenoids de-energize and operate the seat belt retractor. The seatbelt retractor will lock up in the event of a sudden deceleration.


The integrated control unit monitors the shoulder and lap solenoids using switches in the driver's seat belt retractors. When the door is opened and the solenoid is energized, the switches are open. Ground is no longer applied to the integrated control unit at the switch input. When the door is closed the solenoids de-energize and the switches are closed. Ground is applied to the switch input of the integrated control unit.

The automatic seat belt system uses two indicators (door latch indicator and driver's seat belt reminder) in the gauge assembly, a beeper and two indicators (driver's reminder light and passenger's reminder light) in the seat belt beeper/reminder assembly to alert the driver and passenger if there is an existing problem.

Stereo Sound System

Circuit Schematic






Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Under-Hood Relay Box	102
Right side of engine compartment	
C423 (18-WHT)	111
Behind right kick panel	
C425 (6-WHT)	111
Behind right kick panel	
C428 (14-YEL)	72
On rear of dash fuse box	
C440 (16-WHT)	79
On rear of stereo radio cassette player	
C445 (22-WHT)	112
Under right side of dash	
C451 (14-WHT)	58
Behind right kick panel	
C453 (6-WHT)	58
Behind right kick panel	
G401	74
Behind top center of dash	


How The Circuit Works

With the ignition switch in ACC or RUN, voltage is applied through fuse 2 to the radio. When you turn the radio on, current flows through fuse 2 into the receiver circuits in the radio. Fuse 35 is hot at all times and provides power to the radio for its memory circuits.




Power Antenna


Circuit Schematic



Power Antenna (4WS)

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)


Dash Fuse Box	70
Behind left side of dash	
Mast Antenna Retractor Relay	88
Right side of trunk	
Power Antenna Motor	27
Right side of trunk	
Trunk Switch	21
In rear of trunk	
Under-Hood Relay Box	102
Right side of engine compartment	
C428 (14-YEL)	72
On rear of dash fuse box	
C440 (16-WHT)	79
On rear of stereo radio cassette player	
C445 (22-WHT)	112
Under right side of dash	
C486 (13-WHT)	26
Upper right side of trunk	
C501 (4-WHT) (S Model)	26
Right side of trunk	
C501 (8-WHT) (Si Model)	26
Right side of trunk	
C902 (1-WHT)	
Behind LH side of dash, on front of dash fuse box	
G501	26
Right side of trunk	

How The Circuit Works

With the ignition switch in ACC or RUN, voltage is applied through fuse 2 to the radio. Voltage is applied at all times through fuse 35 to the power antenna relay.


When you turn the radio on, the relay coil is energized and the contacts close. Voltage is applied to the power antenna motor: The antenna motor drives the antenna up to its fully extended position.


When you turn the radio off, the relay contacts open. The polarity of the voltage applied to the motor is now reversed: The antenna motor moves the antenna completely down. A mechanical switch controlled by the motor turns the motor off when the antenna reaches maximum height or when the antenna is fully retracted.



Clock

Circuit Schematic





Component Location Index

(Refer to Section 201 for photographs.)

Dash Fuse Box	70
Behind left side of dash	
Under-Hood Relay Box	102
Right side of engine compartment	
C416 (22-WHT)	78
Under left side of dash, right of steering column	
C445 (22-WHT)	112
Under right side of dash	
C723 (4-WHT)	94
Under left side of dash, on dash fuse box	
G471	20
Behind right side of rear seat	


How The Circuit Works

Voltage is applied at all times to the clock through the WHT/YEL wire to provide clock memory. With the ignition switch in RUN or START, voltage is applied to the clock through the YEL wire: The clock lights up and displays the time.




Component Location


1. Left Rear of Engine Compartment




4. Left Front of Engine Compartment (With Cruise Control Actuator Removed)




2. Left Rear of Engine Compartment




5. Left Front of Engine Compartment




3. Left Front of PGM-FI Engine Compartment




6. Left Front of PGM-CARB Engine Compartment







7. Front of PGM-FI Engine Compartment




8. Right Front of PGM-FI Engine
(Air Cleaner Duct Removed)




9. Right Front of Engine Compartment




10. Right Front of Engine Compartment
(Battery Removed)



11. Right Side of Engine Compartment




12. Right Side of Engine Compartment




Component Location


13. Right Front of Engine Compartment
(Battery Removed)




14. Right Front of Engine Compartment




15. Right Rear of PGM-FI Engine Compartment




16. Right Rear of PGM-FI Engine Compartment




17. Left Front of Engine



18. Top Right Side of PGM-FI Engine







19. Rear of Car, Above License Plate




22. In Center of Trunk, Below Rear Deck




20. Right Rear Corner of Passenger Compartment



23. Right Rear of Trunk



21. Rear of Trunk




24. Left Rear Corner of Passenger Compartment




Component Location


25. Left Rear of Trunk




28. Center of Driver's Door (Panel Removed)




26. Right Rear of Si Trunk (S Similar)




29. Front of Driver's Door (Panel Removed)




27. Right Rear of Si Trunk (S Similar)




30. Rear of Driver's Door (Panel Removed)







31. Rear of Driver's Door (Panel Removed)




34. Rear of Passenger's Door (Panel Removed)




32. Center of Passenger's Door (Panel Removed)




35. Front of Passenger's Door (Panel Removed)



33. Rear of Passenger's Door (Panel Removed)




36. Right Rear of PGM-FI Engine Compartment




Component Location


37. Right Rear of PGM-FI Engine Compartment




40. Rear of PGM-FI Engine Compartment




38. Right Front of Car




41. Right Side of Engine




39. Right Front of PGM-FI Engine




42. Right Front of Engine Compartment (Battery Removed)







43. Rear of PGM-FI Engine Compartment




46. Right Side of PGM-FI Engine




44. Left Rear of Engine Compartment




47. Front of PGM-FI Engine Compartment



45. Left Rear of PGM-FI Engine Compartment




48. Right Rear of PGM-CARB Engine Compartment




Component Location


49. Top of PGM-CARB Engine




52. Right Front of Car (Bumper Removed)




50. Rear of PGM-CARB Engine Compartment




53. Left Front of PGM-CARB Engine Compartment




51. Right Front of Engine Compartment




54. Left Front of Car (Bumper Removed)







55. Below Rear of Console (Console Removed)




58. Behind Right Side of Dash (Dash Removed)




56. Left Front of PGM-FI Engine Compartment




59. Behind Center of Dash (Dash Removed)



57. Behind Right Side of Dash (Dash Removed)




60. Below Front of Console (Console Removed)




Component Location


61. Below Right Side of Dash (Dash Removed) (PGM-FI)



64. Behind Center of Dash (Dash Removed) (PGM-FI)




62. Below Left Side of Dash (Dash Removed)




65. Behind Right Side of Dash (Dash Removed)




63. Below Left Side of Dash (Dash Removed)




66. Right Front of Car







67. Left Front of Car




70. Behind Left Side of Dash (Dash Removed)




68. Below Right Side of Dash (PGM-CARB)




71. Below Left Side of Dash (Dash Removed)



69. Left Front of Car




72. Behind Left Side of Dash (Dash Removed)




Component Location


73. Behind Right Side of Dash (Dash Removed)



76. Rear of PGM-FI Engine Compartment




74. Behind Center of Dash (Dash Removed)




77. Center of Dash (Panel Removed)




75. Rear of Dash (Dash Removed)




78. Under Left Side of Dash







79. Center of Dash (Radio and Heater Control Panel Removed)




82. Right Side of Si Trunk




80. Left Side of Dash (Lower Panel Removed)




83. Right Front of PGM-CARB Engine Compartment (Battery Removed)



81. Rear of Gauge Assembly




84. Rear of PGM-CARB Engine Compartment




Component Location


85. Behind Right Side of Dash (Dash Removed)




88. Right Side of Si Trunk




86. Behind Left Side of Dash




89. Right Front of Engine Compartment




87. Top of Steering Column (Steering Wheel Removed)




90. Behind Right Side of Dash (Dash Removed)







91. Behind Right Front Footrest (PGM-FI)




94. Behind Left Side of Dash (Lower Panel Removed)




92. Below Right Front Footrest (PGM-FI)




95. Front of PGM-FI Engine Compartment



93. Below Right Side of Dash




96. Right Side of Engine Compartment




Component Location


97. Right Front of PGM-FI Engine
(Air Cleaner Duct Removed)




100. Below Left Side of Dash, (Lower Panel Removed)




98. Below Left Side of Dash (Dash Removed)




101. Left Rear of PGM-FI Engine Compartment




99. Top Right Side of PGM-FI Engine




102. Right Side of PGM-FI Engine Compartment







103. Right Front of Engine Compartment
(Battery Removal)




106. Underside of Trunk Lid




104. Right Rear of PGM-CARB Engine Compartment




107. Rear of Gauge Assembly



105. Right Rear of PGM-CARB Engine Compartment




108. Left Front of Car (Bumper Removed)




Component Location


109. Front of PGM-FI Engine Compartment




112. Behind Right Side of Dash (Dash Removed)




110. Right Front of PGM-CARB Engine



113. Rear of Drivers Door (Panel Removed)




111. Below Left Side of Dash (Dash Removed)




114. Left Front of Engine Compartment







115. Right Rear of PGM-CARB Engine Compartment




116. Left Door Pillar (Right Similar)





117. Above Center of Windshield



Connector and Wire Harness Routing








(cont'd)

Connector and Wire Harness Routing

(cont'd)








(cont'd)

Connector and Wire Harness Routing

(cont'd)








(cont'd)

Connector and Wire Harness Routing

(cont'd)








(cont'd)

Connector and Wire Harness Routing

(cont'd)








(cont'd)

Connector and Wire Harness Routing

(cont'd)







(cont'd)

Connector and Wire Harness Routing

(cont'd)







" Portions of materials contained herein have been reprinted under license from America Honda Motor Co., Inc. License Agreement AH220 ."